# SECTION 230500 - COMMON WORK RESULTS FOR HVAC

## PART 1 - GENERAL

#### 1.1 SUMMARY

- A. Section Includes:
  - 1. Duct-thermometer mounting brackets.

#### 1.2 DEFINITIONS

A. Existing Piping To Remain: Existing piping that is not to be removed and that is not otherwise indicated to be removed, removed and salvaged, or removed and reinstalled.

#### 1.3 COORDINATION

- A. Coordinate features of motors, installed units, and accessory devices to be compatible with the following:
  - 1. Motor controllers.
  - 2. Torque, speed, and horsepower requirements of the load.
  - 3. Ratings and characteristics of supply circuit and required control sequence.
  - 4. Ambient and environmental conditions of installation location.

### PART 2 - PRODUCTS

### PART 3 - EXECUTION

- 3.1 INSTALLATION OF EXPANSION JOINTS GENERAL
  - A. Install expansion joints of sizes matching sizes of piping in which they are installed.

# 3.2 INSTALLATION OF PIPE LOOPS AND SWING CONNECTIONS

- A. Install pipe loops cold-sprung in tension or compression as required to partly absorb tension or compression produced during anticipated change in temperature.
- B. Connect risers and branch connections to mains with at least pipe fittings, including tee in main.
- C. Connect risers and branch connections to terminal units with at least pipe fittings, including tee in riser.

D. Connect mains and branch connections to terminal units with at least pipe fittings, including tee in main.

# 3.3 INSTALLATION OF SLEEVES - GENERAL

- A. Install sleeves for piping passing through penetrations in floors, partitions, roofs, and walls.
- B. For sleeves that will have sleeve-seal system installed, select sleeves of size large enough to provide [1-inch] [2-inch] <**Insert dimension**> annular clear space between piping and concrete slabs and walls.
  - 1. Sleeves are not required for core-drilled holes.
- C. Install sleeves in concrete floors, concrete roof slabs, and concrete walls as new slabs and walls are constructed.
  - 1. Permanent sleeves are not required for holes in slabs formed by molded-PE or -PP sleeves.
  - 2. Cut sleeves to length for mounting flush with both surfaces.
    - a. Exception: Extend sleeves installed in floors of mechanical equipment areas or other wet areas [2 inches] <**Insert dimension**> above finished floor level.
  - 3. Using [grout] [or] [silicone sealant], seal space outside of sleeves in floors/slabs/walls without sleeve-seal system. Select to maintain fire resistance of floor/slab/wall.
- D. Install sleeves for pipes passing through interior partitions.
  - 1. Cut sleeves to length for mounting flush with both surfaces.
  - 2. Install sleeves that are large enough to provide 1/4-inch annular clear space between sleeve and pipe or pipe insulation.
  - 3. Seal annular space between sleeve and piping or piping insulation; use joint sealants that joint sealant manufacturer's literature indicates is appropriate for size, depth, and location of joint.
- E. Fire-Resistance-Rated Penetrations, Horizontal Assembly Penetrations, and Smoke-Barrier Penetrations: Maintain indicated fire or smoke rating of walls, partitions, ceilings, and floors at pipe penetrations. Seal pipe penetrations with fire- and smoke-stop materials. Comply with requirements for firestopping and fill materials specified in Section 078413 "Penetration Firestopping."

# 3.4 INSTALLATION OF METERS AND GAUGES

- A. Install thermowells with socket extending [a minimum of 2 inches into fluid] [one-third of pipe diameter] [to center of pipe] and in vertical position in piping tees.
- B. Install thermowells of sizes required to match thermometer connectors. Include bushings if required to match sizes.

- C. Install thermowells with extension on insulated piping.
- D. Fill thermowells with heat-transfer medium.
- E. Install direct-mounted thermometers in thermowells and adjust vertical and tilted positions.
- F. Install remote-mounted thermometer bulbs in thermowells and install cases on panels; connect cases with tubing, and support tubing to prevent kinks. Use minimum tubing length.
- G. Install pipe-mounted thermal-energy temperature sensors in thermowells and extend wiring to indicator.
- H. Install duct-thermometer-mounting brackets in walls of ducts. Attach to duct with screws.
- I. Install direct-mounted pressure gauges in piping tees with pressure gauge located on pipe at the most readable position.
- J. Install remote-mounted pressure gauges on panel.
- K. Install valve and snubber in piping for each pressure gauge for fluids (except steam).
- L. Install valve and syphon fitting in piping for each pressure gauge for steam.
- M. Install test plugs in piping tees.
- N. Install flow indicators in piping systems in accessible positions for easy viewing.
- O. Assemble and install connections, tubing, and accessories between flow-measuring elements and flowmeters according to manufacturer's written instructions.
- P. Install flowmeter elements in accessible positions in piping systems.
- Q. Install wafer-orifice flowmeter elements between orifice-type pipe flanges.
- R. Install all flowmeter elements, with at least minimum straight lengths of pipe, upstream and downstream from element according to manufacturer's written instructions.
- S. Install permanent indicators on walls or brackets in accessible and readable positions.
- T. Install connection fittings in accessible locations for attachment to portable indicators.
- U. Mount thermal-energy meters on wall if accessible; if not, provide brackets to support meters.
- V. Install thermometers in the following locations:
  - 1. Inlet and outlet of each hydronic zone.
  - 2. Inlet and outlet of each hydronic boiler.
  - 3. Two inlets and two outlets of each chiller.
  - 4. Inlet and outlet of each hydronic coil in air-handling units.
  - 5. Two inlets and two outlets of each hydronic heat exchanger.
  - 6. Inlet and outlet of each thermal-storage tank.

- 7. Outside-, return-, supply-, and mixed-air ducts.
- 8. <**Insert location**>.
- W. Install pressure gauges in the following locations:
  - 1. Discharge of each pressure-reducing valve.
  - 2. Inlet and outlet of each chiller chilled-water and condenser-water connection.
  - 3. Suction and discharge of each pump.
  - 4. <**Insert location**>.

## 3.5 CONNECTIONS

- A. Install meters and gauges adjacent to machines and equipment to allow space for service and maintenance of meters, gauges, machines, and equipment.
- B. Connect flowmeter-system elements to meters.
- C. Connect flowmeter transmitters to meters.
- D. Connect thermal-energy meter transmitters to meters.

## 3.6 ADJUSTING

- A. After installation, calibrate meters according to manufacturer's written instructions.
- B. Adjust faces of meters and gauges to proper angle for best visibility.

### 3.7 SLEEVES APPLICATION

- A. Use sleeves and sleeve seals for the following piping-penetration applications:
  - 1. Concrete Slabs above Grade:

### 3.8 THERMOMETER APPLICATION

- A. Thermometers at inlet and outlet of each hydronic zone are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [**Direct**] [**Remote**]-mounted, -case, vapor-actuated type.
  - 3. [**Compact**] [**Industrial**]-style, liquid-in-glass type.
  - 4. [**Direct**] [**Remote**]-mounted, light-activated type.
  - 5. Test plug with self-sealing rubber inserts.
- B. Thermometers at inlet and outlet of each hydronic boiler are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [Direct] [Remote]-mounted, -case, vapor-actuated type.
  - 3. [Compact] [Industrial]-style, liquid-in-glass type.

- 4. [**Direct**] [**Remote**]-mounted, light-activated type.
- 5. Test plug with self-sealing rubber inserts.
- C. Thermometers at inlets and outlets of each chiller are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [Direct] [Remote]-mounted, -case, vapor-actuated type.
  - 3. [**Compact**] [**Industrial**]-style, liquid-in-glass type.
  - 4. [**Direct**] [**Remote**]-mounted, light-activated type.
  - 5. Test plug with self-sealing rubber inserts.
- D. Thermometers at inlet and outlet of each hydronic coil in air-handling units and built-up central systems are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [Direct] [Remote]-mounted, -case, vapor-actuated type.
  - 3. [Compact] [Industrial]-style, liquid-in-glass type.
  - 4. [Direct] [Remote]-mounted, light-activated type.
  - 5. Test plug with self-sealing rubber inserts.
- E. Thermometers at inlets and outlets of each hydronic heat exchanger are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [**Direct**] [**Remote**]-mounted, -case, vapor-actuated type.
  - 3. [Compact] [Industrial]-style, liquid-in-glass type.
  - 4. [**Direct**] [**Remote**]-mounted, light-activated type.
  - 5. Test plug with self-sealing rubber inserts.
- F. Thermometers at inlet and outlet of each hydronic heat-recovery unit are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [**Direct**] [**Remote**]-mounted, -case, vapor-actuated type.
  - 3. [Compact] [Industrial]-style, liquid-in-glass type.
  - 4. [**Direct**] [**Remote**]-mounted, light-activated type.
  - 5. Test plug with self-sealing rubber inserts.
- G. Thermometers at inlet and outlet of each thermal-storage tank are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [**Direct**] [**Remote**]-mounted, -case, vapor-actuated type.
  - 3. [Compact] [Industrial]-style, liquid-in-glass type.
  - 4. [**Direct**] [**Remote**]-mounted, light-activated type.
  - 5. Test plug with self-sealing rubber inserts.
- H. Thermometers at outside-, return-, supply-, and mixed-air ducts are to be the following:
  - 1. , bimetallic-actuated type.
  - 2. [**Direct**] [**Remote**]-mounted, -case, vapor-actuated type.
  - 3. [**Compact**] [**Industrial**]-style, liquid-in-glass type.
  - 4. [**Direct**] [**Remote**]-mounted, light-activated type.

I. Thermometer stems are to be of length to match thermowell insertion length.

## 3.9 THERMOMETER SCALE-RANGE APPLICATION

- A. Scale Range for Chilled-Water Piping:
  - 1. [Minus 40 to plus 160 deg F] [Minus 40 to plus 160 deg F and minus 40 to plus 100 deg C].
  - 2. [0 to 100 deg F] [0 to 100 deg F and minus 20 to plus 50 deg C].
  - 3. [0 to 150 deg F] [0 to 150 deg F and minus 20 to plus 70 deg C].
  - 4. [0 to 250 deg F] [0 to 250 deg F and 0 to 150 deg C].
- B. Scale Range for Condenser-Water Piping:
  - 1. [0 to 100 deg F] [0 to 100 deg F and minus 20 to plus 50 deg C].
  - 2. [0 to 150 deg F] [0 to 150 deg F and minus 20 to plus 70 deg C].
  - 3. [0 to 250 deg F] [0 to 250 deg F and 0 to 150 deg C].
  - 4. [20 to 240 deg F] [20 to 240 deg F and 0 to 150 deg C].
  - 5. [30 to 240 deg F] [30 to 240 deg F and 0 to plus 115 deg C].
- C. Scale Range for Heating, Hot-Water Piping:
  - 1. [0 to 250 deg F] [0 to 250 deg F and 0 to 150 deg C].
  - 2. [20 to 240 deg F] [20 to 240 deg F and 0 to 150 deg C].
  - 3. [30 to 240 deg F] [30 to 240 deg F and 0 to plus 115 deg C].
  - 4. [50 to 400 deg F] [50 to 400 deg F and 0 to 200 deg C].
  - 5. [50 to 550 deg F] [50 to 550 deg F and 10 to 300 deg C].
- D. Scale Range for Steam and Steam-Condensate Piping:
  - 1. [0 to 250 deg F] [0 to 250 deg F and 0 to 150 deg C].
  - 2. [0 to 250 deg F] [0 to 250 deg F and 0 to 150 deg C].
  - 3. [30 to 240 deg F] [30 to 240 deg F and 0 to plus 115 deg C].
  - 4. [50 to 400 deg F] [50 to 400 deg F and 0 to 200 deg C].
- E. Scale Range for Air Ducts:
  - 1. [Minus 40 to plus 110 deg F] [Minus 40 to plus 110 deg F and minus 40 to plus 45 deg C].
  - 2. [Minus 40 to plus 160 deg F] [Minus 40 to plus 160 deg F and minus 40 to plus 100 deg C].
  - 3. [0 to 100 deg F] [0 to 100 deg F and minus 20 to plus 50 deg C].
  - 4. [0 to 150 deg F] [0 to 150 deg F and minus 20 to plus 70 deg C].
  - 5. [0 to 250 deg F] [0 to 250 deg F and 0 to 150 deg C].
  - 6. [20 to 240 deg F] [20 to 240 deg F and 0 to 150 deg C].
  - 7. [30 to 240 deg F] [30 to 240 deg F and 0 to plus 115 deg C].
  - 8. [50 to 400 deg F] [50 to 400 deg F and 0 to 200 deg C].

### 3.10 PRESSURE-GAUGE SCALE-RANGE APPLICATION

- A. Scale Range for Chilled-Water Piping:
  - 1. [30 in. Hg to 15 psi] [**30 in. Hg to 15 psi and minus 100 to 0 kPa**].
  - 2. [0 to 30 psi] [0 to 30 psi and 0 to 240 kPa].
  - 3. [0 to 100 psi] [0 to 100 psi and 0 to 600 kPa].
  - 4. [0 to 160 psi] [0 to 160 psi and 0 to 1100 kPa].
  - 5. [0 to 200 psi] [0 to 200 psi and 0 to 1400 kPa].
  - 6. [0 to 300 psi] [0 to 300 psi and 0 to 2500 kPa].
  - 7. [0 to 600 psi] [0 to 600 psi and 0 to 4000 kPa].
- B. Scale Range for Condenser-Water Piping:
  - 1. [30 in. Hg to 15 psi] [**30 in. Hg to 15 psi and minus 100 to 0 kPa**].
  - 2. [0 to 30 psi] [0 to 30 psi and 0 to 240 kPa].
  - 3. [0 to 100 psi] [0 to 100 psi and 0 to 600 kPa].
  - 4. [0 to 160 psi] [0 to 160 psi and 0 to 1100 kPa].
  - 5. [0 to 200 psi] [0 to 200 psi and 0 to 1400 kPa].
  - 6. [0 to 300 psi] [0 to 300 psi and 0 to 2500 kPa].
  - 7. [0 to 600 psi] [0 to 600 psi and 0 to 4000 kPa].
- C. Scale Range for Heating, Hot-Water Piping:
  - 1. [30 in. Hg to 15 psi] [**30 in. Hg to 15 psi and minus 100 to 0 kPa**].
  - 2. [0 to 30 psi] [0 to 30 psi and 0 to 240 kPa].
  - 3. [0 to 100 psi] [0 to 100 psi and 0 to 600 kPa].
  - 4. [0 to 160 psi] [0 to 160 psi and 0 to 1100 kPa].
  - 5. [0 to 200 psi] [0 to 200 psi and 0 to 1400 kPa].
  - 6. [0 to 300 psi] [0 to 300 psi and 0 to 2500 kPa].
  - 7. [0 to 600 psi] [0 to 600 psi and 0 to 4000 kPa].
- D. Scale Range for Steam Piping:
  - 1. [30 in. Hg to 15 psi] [**30 in. Hg to 15 psi and minus 100 to 0 kPa**].
  - 2. [0 to 30 psi] [0 to 30 psi and 0 to 240 kPa].
  - 3. [0 to 100 psi] [0 to 100 psi and 0 to 600 kPa].
  - 4. [0 to 160 psi] [0 to 160 psi and 0 to 1100 kPa].
  - 5. [0 to 200 psi] [0 to 200 psi and 0 to 1400 kPa].
  - 6. [0 to 300 psi] [0 to 300 psi and 0 to 2500 kPa].
  - 7. [0 to 600 psi] [0 to 600 psi and 0 to 4000 kPa].

# 3.11 THERMAL-ENERGY METER APPLICATION

- A. Thermal-Energy Meters for Chilled-Water Piping: [**Turbine**] [**Ultrasonic**] type.
- B. Thermal-Energy Meters for Condenser-Water Piping: [Turbine] [Ultrasonic] type.

- C. Thermal-Energy Meters for Heating, Hot-Water Piping: [**Turbine**] [**Ultrasonic**] type.
- D. Thermal-Energy Meters for Steam and Steam-Condensate Piping: [**Turbine**] [**Ultrasonic**] type.

END OF SECTION 230500

# SECTION 230548.13 - VIBRATION CONTROLS FOR HVAC

## PART 1 - GENERAL

#### 1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

#### 1.2 DEFINITIONS

- A. IBC: International Building Code.
- B. OSHPD: Office of Statewide Health Planning and Development (for the State of California owned and regulated medical facilities).

#### PART 2 - PRODUCTS

#### 2.1 PERFORMANCE REQUIREMENTS

- A. Delegated Design: Engage a qualified professional engineer, as defined in Section 014000 "Quality Requirements," to design system.
  - 1. Wind-Load Performance: Equipment shall withstand the effects of high wind events determined in accordance with [ASCE/SEI 7-05] [ASCE/SEI 7-10] [ASCE/SEI 7-16] <Insert requirement>.
- B. Wind-Load Design Calculations:
  - Perform calculations to obtain force information necessary to properly select wind-load-restraint devices, fasteners, and anchorage. Perform calculations using methods acceptable to applicable code authorities and as presented in [ASCE/SEI 7-05] [ASCE/SEI 7-10] [ASCE/SEI 7-16] <Insert ASCE/SEI 7 edition or other wind-force calculation method required by authorities having jurisdiction>. Where "ASCE/SEI 7" is used throughout this Section, it is to be understood that the edition referred to in this subparagraph is intended as referenced throughout the Section Text unless otherwise noted.
    - a. Factors indicated below that are specific to individual pieces of equipment must be obtained by Contractor and must be included in individual component submittal packages.
    - b. Coordinate design wind-load calculations with vibration isolation requirements. Comply with requirements in other Sections in addition to those in this Section for equipment mounted outdoors.

- 2. Design wind pressure "p" for external sidewall-mounted equipment such as louvers is to be calculated by Delegated-Design Contractor using methods in ASCE/SEI 7-16, Ch. 30. Perform calculations in accordance with one of the following, as appropriate:
  - a. PART 1: Low-Rise Buildings.
  - b. PART 2: Low-Rise Buildings (Simplified).
  - c. PART 3: Buildings with "h" less than 60 feet.
  - d. PART 4: Buildings with "h" greater than 60 feet and less than 160 feet.
  - e. PART 5: Open Buildings.
- 3. Design wind pressure "p" for rooftop equipment is to be calculated by Delegated-Design Contractor using methods in ASCE/SEI 7-16, Ch. 30, PART 6: Building Appurtenances and Rooftop Structures and Equipment.
  - a. Risk Category: [I] [II] [III] [IV] [V].
  - b. h = Mean Roof Height: **<Insert value**>.
  - c. V = Basic Wind Speed: <**Insert value**>.
  - d. K<sub>d</sub> = Wind Directionality Factor: **<Insert factor**>.
  - e. Exposure Category: [**B**] [**C**] [**D**].
  - f. K<sub>zt</sub> = Topographic Factor: <**Insert factor**>.
  - g. K<sub>e</sub> = Ground Elevation Factor: <**Insert factor**>.
  - h. K<sub>z</sub> = Velocity Pressure Exposure Coefficient (Evaluated at Height z): <**Insert** coefficient>.
  - i. K<sub>h</sub> = Velocity Pressure Exposure Coefficient (Evaluated at Height h): <**Insert** coefficient>.
  - j. q<sub>z</sub> = Velocity Pressure: Value calculated by delegated wind-load design Contractor using methods detailed in ASCE/SEI 7-16 Section 26.10.1 or other source approved by authorities having jurisdiction.
  - k. q<sub>h</sub> = Velocity Pressure: Value calculated by delegated wind-load design Contractor using methods detailed in ASCE/SEI 7-16 Section 26.10.1 or other source approved by authorities having jurisdiction.
  - 1. G = Gust-Effect Factor: [0.85] <Insert factor>.
  - m. Enclosure Classification: < Insert classification>.
  - n.  $GC_{pi} = Internal Pressure Coefficient: < Insert coefficient>.$
- 4. Design wind pressure "p" for external sidewall-mounted equipment such as louvers are to be calculated by Delegated-Design Contractor using methods in ASCE/SEI 7-10, Ch. 30. Perform calculations in accordance with one of the following, as appropriate:
  - a. PART 1: Low-Rise Buildings.
  - b. PART 2: Low-Rise Buildings (Simplified).
  - c. PART 3: Buildings with "h" greater than 60 feet.
  - d. PART 4: Buildings with "h" less than 160 feet.
  - e. PART 5: Open Buildings.
- 5. Design wind pressure "p" for rooftop equipment is to be calculated by Delegated-Design Contractor using methods in ASCE/SEI 7-10, Ch. 30, PART 6: Building Appurtenances and Rooftop Structures and Equipment.
  - a. Risk Category: [I] [II] [III] [IV] [V].

- b. h = Mean roof height: **<Insert value**>.
- c. V = Basic Wind Speed: <**Insert value**>.
- d. K<sub>d</sub> = Wind Directionality Factor: <**Insert factor**>.
- e. Exposure Category: [B] [C] [D].
- $f. \qquad K_{zt} = Topographic \ Factor: < Insert \ factor>.$
- g. K<sub>z</sub> = Velocity Pressure Exposure Coefficient (Evaluated at Height z): <**Insert** coefficient>.
- h. K<sub>h</sub> = Velocity Pressure Exposure Coefficient (Evaluated at Height h): <**Insert** coefficient>.
- i.  $q_z$  = Velocity Pressure at Height z: Value calculated by delegated wind-load design Contractor using methods detailed in ASCE/SEI 7-10 Section 26.10.1 or other source approved by authorities having jurisdiction.
- j. q<sub>h</sub> = Velocity Pressure at Height h: Value calculated by delegated wind-load design Contractor using methods detailed in ASCE/SEI 7-10 Section 26.10.1 or other source approved by authorities having jurisdiction.
- k. G = Gust-Effect Factor: [0.85] <Insert factor>.
- 1. Enclosure Classification: <**Insert classification**>.
- m.  $GC_{pi}$  = Internal Pressure Coefficient: <**Insert coefficient**>.
- 6. Design wind force "F" for rooftop equipment and external sidewall-mounted equipment such as louvers is to be calculated by Delegated-Design Contractor using methods in ASCE/SEI 7-05, Ch. 6.
  - a. I = Importance Factor: <**Insert factor**>.
  - b. h = Mean Roof Height: **<Insert value**>.
  - c. V = Basic Wind Speed: <**Insert value**>.
  - d. K<sub>d</sub> = Wind Directionality Factor: <**Insert factor**>.
  - e. Exposure Category: [**B**] [**C**] [**D**].
  - f. K<sub>zt</sub> = Topographic Factor: **<Insert factor**>.
  - g. K<sub>z</sub> = Velocity Pressure Exposure Coefficient (Evaluated at Height z): <**Insert** coefficient>.
  - h. K<sub>h</sub> = Velocity Pressure Exposure Coefficient (Evaluated at Height h): <**Insert** coefficient>.
  - i.  $q_z$  = Velocity Pressure at Height z: Value calculated by delegated wind-load design Contractor using methods detailed in ASCE/SEI 7-05 Section 6.5.10 or other source approved by authorities having jurisdiction.
  - j.  $q_h$  = Velocity Pressure at Roof Height h: Value calculated by delegated wind-load design Contractor using methods detailed in ASCE/SEI 7-05 Section 6.5.10 or other source approved by authorities having jurisdiction.
  - k. G = Gust-Effect Factor: [0.85] <Insert factor>.
  - 1. GC<sub>pi</sub> = Internal Pressure Coefficient: <**Insert coefficient**>.
  - m.  $GC_p = External Pressure Coefficient: < Insert coefficient>.$
  - n.  $C_f$  = Force Coefficient: Value determined by delegated wind-load design Contractor from ASCE/SEI 7-05, Figures 6-21 through 6-23 or other source approved by authorities having jurisdiction.
  - o.  $A_f = Projected Area Normal to the Wind: Except where "Cf" is specified for the actual surface area. Value determined by delegated wind-load design Contractor from equipment submittal or manufacturer.$

- C. Consequential Damage: Provide additional restraints for suspended HVAC components or anchorage of floor-, roof-, or wall-mounted HVAC components as indicated in [ASCE/SEI 7-05] [ASCE/SEI 7-10] [ASCE/SEI 7-16] so that failure of a non-essential or essential HVAC component will not cause the failure of any other essential architectural, mechanical, or electrical building component.
- D. Fire/Smoke Resistance: All components that are not constructed of ferrous metals must have a maximum flame-spread index of 25 and maximum smoke-developed index of 50 when tested by an NRTL in accordance with ASTM E84 or UL 723, and be so labeled.
- E. Component Supports:
  - 1. Load ratings, features, and applications of all reinforcement components must be based on testing standards of a nationally recognized testing agency.

## PART 3 - EXECUTION

### 3.1 EXAMINATION

- A. Examine areas and equipment to receive vibration isolation [**and wind-load control**]devices for compliance with requirements for installation tolerances and other conditions affecting performance of the Work.
- B. Examine roughing-in of reinforcement and cast-in-place anchors to verify actual locations before installation.
- C. Proceed with installation only after unsatisfactory conditions have been corrected.

### 3.2 APPLICATIONS

- A. Multiple Pipe Supports: Secure pipes to trapeze member with clamps approved for application by [an evaluation service member of ICC-ES] [OSHPD] [an agency acceptable to authorities having jurisdiction].
- B. Strength of Support Assemblies: Where not indicated, select sizes of components so strength is adequate to carry static and wind force loads within specified loading limits.

### 3.3 INSTALLATION OF VIBRATION [AND WIND-LOAD ]CONTROL DEVICES

- A. Provide vibration [**and wind-load**] control devices for systems and equipment where indicated in Equipment Schedules or Vibration-Control Device Schedules on Drawings, where Specifications indicate they are to be installed on specific equipment and systems, and where required by applicable codes.
- B. Coordinate location of embedded connection hardware with supported equipment attachment and mounting points and with requirements for concrete reinforcement and formwork specified in Section 033000 "Cast-in-Place Concrete."

- C. Installation of vibration isolators[ **and wind-load restraints**] must not cause any change of position of equipment, piping, or ductwork resulting in stresses or misalignment.
- D. Comply with requirements in Section 077200 "Roof Accessories" for installation of roof curbs, equipment supports, and roof penetrations.
- E. Equipment Restraints:
  - 1. Install snubbers on HVAC equipment mounted on vibration isolators. Locate snubbers as close as possible to vibration isolators and bolt to equipment base and supporting structure.
  - 2. Install resilient bolt isolation washers on equipment anchor bolts where clearance between anchor and adjacent surface exceeds 0.125 inch.
  - 3. Install wind-load-restraint devices using methods approved by [an evaluation service member of ICC-ES] [OSHPD] [an agency acceptable to authorities having jurisdiction] that provides required submittals for component.
- F. Piping Restraints:
  - 1. Comply with requirements in MSS SP-127.
  - 2. Space lateral supports a maximum of [40 feet] <**Insert dimension**> o.c., and longitudinal supports a maximum of [80 feet] <**Insert dimension**> o.c.
  - 3. Brace a change of direction longer than 12 feet.
- G. Install wind-load-restraint cables so they do not bend across edges of adjacent equipment or building structure.
- H. Install wind-load-restraint devices using methods approved by [an evaluation service member of ICC-ES] [OSHPD] [an agency acceptable to authorities having jurisdiction] that provides required submittals for component.
- I. Install bushing assemblies for anchor bolts for floor-mounted equipment, arranged to provide resilient media between anchor bolt and mounting hole in concrete base.
- J. Install bushing assemblies for mounting bolts for wall-mounted equipment, arranged to provide resilient media where equipment or equipment-mounting channels are attached to wall.
- K. Attachment to Structure: If specific attachment is not indicated, anchor bracing to structure at flanges of beams, at upper truss chords of bar joists, or at concrete members.

# 3.4 ADJUSTING

- A. Adjust isolators after system is at operating weight.
- B. Adjust limit stops on restrained-spring isolators to mount equipment at normal operating height. After equipment installation is complete, adjust limit stops so they are out of contact during normal operation.

END OF SECTION 230548.13

# SECTION 230553 - IDENTIFICATION FOR HVAC PIPING AND EQUIPMENT

PART 1 - GENERAL

## PART 2 - PRODUCTS

### PART 3 - EXECUTION

#### 3.1 PREPARATION

A. Clean piping and equipment surfaces of incompatible primers, paints, and encapsulants, as well as dirt, oil, grease, release agents, and other substances that could impair bond of identification devices.

#### 3.2 INSTALLATION, GENERAL REQUIREMENTS

- A. Coordinate installation of identifying devices with completion of covering and painting of surfaces where devices are to be applied.
- B. Coordinate installation of identifying devices with locations of access panels and doors.
- C. Install identifying devices before installing acoustical ceilings and similar concealment.
- D. Locate identifying devices so that they are readily visible from the point of normal approach.

#### 3.3 INSTALLATION OF EQUIPMENT LABELS, WARNING SIGNS, AND LABELS

- A. Permanently fasten labels on each item of mechanical equipment.
- B. Sign and Label Colors:

#### 1. [White letters on an ANSI Z535.1 safety-blue background] <Insert colors>.

- C. Locate equipment labels where accessible and visible.
- D. Arc-Flash Warning Signs: Provide arc-flash warning signs on electrical disconnects and other equipment where arc-flash hazard exists, as indicated on Drawings, and in accordance with requirements of OSHA and NFPA 70E[, and other applicable codes and standards].

END OF SECTION 230553

# SECTION 230593 - TESTING, ADJUSTING, AND BALANCING FOR HVAC

## PART 1 - GENERAL

#### 1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

#### 1.2 DEFINITIONS

- A. AABC: Associated Air Balance Council.
- B. BAS: Building automation systems.
- C. NEBB: National Environmental Balancing Bureau.
- D. TAB: Testing, adjusting, and balancing.
- E. TABB: Testing, Adjusting, and Balancing Bureau.
- F. TAB Specialist: An independent entity meeting qualifications to perform TAB work.
- G. TDH: Total dynamic head.

#### 1.3 FIELD CONDITIONS

- A. Full Owner Occupancy: Owner will occupy the site and existing building during entire TAB period. Cooperate with Owner during TAB operations to minimize conflicts with Owner's operations.
- B. Partial Owner Occupancy: Owner may occupy completed areas of building before Substantial Completion. Cooperate with Owner during TAB operations to minimize conflicts with Owner's operations.

### PART 2 - PRODUCTS (Not Applicable)

### PART 3 - EXECUTION

#### 3.1 TAB SPECIALISTS

A. Subject to compliance with requirements, [engage one of the following] [available TAB specialists that may be engaged include, but are not limited to, the following]:

# 1. <Insert TAB specialist's name>.

## 3.2 EXAMINATION

- A. Examine the Contract Documents to become familiar with Project requirements and to discover conditions in systems designs that may preclude proper TAB of systems and equipment.
- B. Examine installed systems for balancing devices, such as test ports, gage cocks, thermometer wells, flow-control devices, balancing valves and fittings, and manual volume dampers. Verify that locations of these balancing devices are applicable for intended purpose and are accessible.
- C. Examine the approved submittals for HVAC systems and equipment.
- D. Examine design data including HVAC system descriptions, statements of design assumptions for environmental conditions and systems output, and statements of philosophies and assumptions about HVAC system and equipment controls.
- E. Examine ceiling plenums and underfloor air plenums used for supply, return, or relief air to verify that they are properly separated from adjacent areas. Verify that penetrations in plenum walls are sealed and fire-stopped if required.
- F. Examine equipment performance data including fan and pump curves.
  - 1. Relate performance data to Project conditions and requirements, including system effects that can create undesired or unpredicted conditions that cause reduced capacities in all or part of a system.
  - 2. Calculate system-effect factors to reduce performance ratings of HVAC equipment when installed under conditions different from the conditions used to rate equipment performance. To calculate system effects for air systems, use tables and charts found in AMCA 201, "Fans and Systems," or in SMACNA's "HVAC Systems Duct Design." Compare results with the design data and installed conditions.
- G. Examine system and equipment installations and verify that field quality-control testing, cleaning, and adjusting specified in individual Sections have been performed.
- H. Examine test reports specified in individual system and equipment Sections.
- I. Examine HVAC equipment and verify that bearings are greased, belts are aligned and tight, filters are clean, and equipment with functioning controls is ready for operation.
- J. Examine terminal units, such as variable-air-volume boxes, and verify that they are accessible and their controls are connected and functioning.
- K. Examine strainers. Verify that startup screens have been replaced by permanent screens with indicated perforations.
- L. Examine control valves for proper installation for their intended function of throttling, diverting, or mixing fluid flows.
- M. Examine heat-transfer coils for correct piping connections and for clean and straight fins.

- N. Examine system pumps to ensure absence of entrained air in the suction piping.
- O. Examine operating safety interlocks and controls on HVAC equipment.
- P. Report deficiencies discovered before and during performance of TAB procedures. Observe and record system reactions to changes in conditions. Record default set points if different from indicated values.

## 3.3 PREPARATION

- A. Prepare a TAB plan that includes the following:
  - 1. Equipment and systems to be tested.
  - 2. Strategies and step-by-step procedures for balancing the systems.
  - 3. Instrumentation to be used.
  - 4. Sample forms with specific identification for all equipment.
- B. Perform system-readiness checks of HVAC systems and equipment to verify system readiness for TAB work. Include, at a minimum, the following:
  - 1. Airside:
    - a. Verify that leakage and pressure tests on air distribution systems have been satisfactorily completed.
    - b. Duct systems are complete with terminals installed.
    - c. Volume, smoke, and fire dampers are open and functional.
    - d. Clean filters are installed.
    - e. Fans are operating, free of vibration, and rotating in correct direction.
    - f. Variable-frequency controllers' startup is complete and safeties are verified.
    - g. Automatic temperature-control systems are operational.
    - h. Ceilings are installed.
    - i. Windows and doors are installed.
    - j. Suitable access to balancing devices and equipment is provided.
  - 2. Hydronics:
    - a. Verify leakage and pressure tests on water distribution systems have been satisfactorily completed.
    - b. Piping is complete with terminals installed.
    - c. Water treatment is complete.
    - d. Systems are flushed, filled, and air purged.
    - e. Strainers are pulled and cleaned.
    - f. Control valves are functioning per the sequence of operation.
    - g. Shutoff and balance valves have been verified to be 100 percent open.
    - h. Pumps are started and proper rotation is verified.
    - i. Pump gage connections are installed directly at pump inlet and outlet flanges or in discharge and suction pipe prior to valves or strainers.
    - j. Variable-frequency controllers' startup is complete and safeties are verified.
    - k. Suitable access to balancing devices and equipment is provided.

### 3.4 GENERAL PROCEDURES FOR TESTING AND BALANCING

- A. Perform testing and balancing procedures on each system according to the procedures contained in [AABC's "National Standards for Total System Balance"] [ASHRAE 111]
  [NEBB's "Procedural Standards for Testing, Adjusting, and Balancing of Environmental Systems"] [SMACNA's "HVAC Systems Testing, Adjusting, and Balancing"] and in this Section.
- B. Cut insulation, ducts, pipes, and equipment cabinets for installation of test probes to the minimum extent necessary for TAB procedures.
  - 1. After testing and balancing, patch probe holes in ducts with same material and thickness as used to construct ducts.
  - 2. After testing and balancing, install test ports and duct access doors that comply with requirements in Section 233300 "Air Duct Accessories."
  - 3. Install and join new insulation that matches removed materials. Restore insulation, coverings, vapor barrier, and finish according to Section 230713 "Duct Insulation," Section 230716 "HVAC Equipment Insulation," and Section 230719 "HVAC Piping Insulation."
- C. Mark equipment and balancing devices, including damper-control positions, valve position indicators, fan-speed-control levers, and similar controls and devices, with paint or other suitable, permanent identification material to show final settings.
- D. Take and report testing and balancing measurements in [inch-pound (IP)] [and] [metric (SI)] units.

### 3.5 TOLERANCES

- A. Set HVAC system's airflow rates and water flow rates within the following tolerances:
  - 1. Supply, Return, and Exhaust Fans and Equipment with Fans: [Plus or minus 10 percent] </br>Insert value>.
  - 2. Air Outlets and Inlets: [Plus or minus 10 percent] <Insert value>.
  - 3. Heating-Water Flow Rate: [Plus or minus 10 percent] <Insert value>.
  - 4. Cooling-Water Flow Rate: [Plus or minus 10 percent] <Insert value>.
- B. Maintaining pressure relationships as designed shall have priority over the tolerances specified above.

# 3.6 PROGRESS REPORTING

- A. Initial Construction-Phase Report: Based on examination of the Contract Documents as specified in "Examination" Article, prepare a report on the adequacy of design for systems balancing devices. Recommend changes and additions to systems balancing devices to facilitate proper performance measuring and balancing. Recommend changes and additions to HVAC systems and general construction to allow access for performance measuring and balancing devices.
- B. Status Reports: Prepare [weekly] [biweekly] [monthly] <Insert time interval> progress reports to describe completed procedures, procedures in progress, and scheduled procedures. Include a list of deficiencies and problems found in systems being tested and balanced. Prepare a separate report for each system and each building floor for systems serving multiple floors.

## 3.7 FINAL REPORT

- A. General: Prepare a certified written report; tabulate and divide the report into separate sections for tested systems and balanced systems.
  - 1. Include a certification sheet at the front of the report's binder, signed and sealed by the certified testing and balancing engineer.
  - 2. Include a list of instruments used for procedures, along with proof of calibration.
  - 3. Certify validity and accuracy of field data.
- B. Final Report Contents: In addition to certified field-report data, include the following:
  - 1. Pump curves.
  - 2. Fan curves.
  - 3. Manufacturers' test data.
  - 4. Field test reports prepared by system and equipment installers.
  - 5. Other information relative to equipment performance; do not include Shop Drawings and Product Data.
- C. General Report Data: In addition to form titles and entries, include the following data:
  - 1. Title page.
  - 2. Name and address of the TAB specialist.
  - 3. Project name.
  - 4. Project location.
  - 5. Architect's name and address.
  - 6. Engineer's name and address.
  - 7. Contractor's name and address.
  - 8. Report date.
  - 9. Signature of TAB supervisor who certifies the report.
  - 10. Table of Contents with the total number of pages defined for each section of the report. Number each page in the report.
  - 11. Summary of contents including the following:

- a. Indicated versus final performance.
- b. Notable characteristics of systems.
- c. Description of system operation sequence if it varies from the Contract Documents.
- 12. Nomenclature sheets for each item of equipment.
- 13. Data for terminal units, including manufacturer's name, type, size, and fittings.
- 14. Notes to explain why certain final data in the body of reports vary from indicated values.
- 15. Test conditions for fans and pump performance forms including the following:
  - a. Settings for outdoor-, return-, and exhaust-air dampers.
  - b. Conditions of filters.
  - c. Cooling coil, wet- and dry-bulb conditions.
  - d. Face and bypass damper settings at coils.
  - e. Fan drive settings including settings and percentage of maximum pitch diameter.
  - f. Inlet vane settings for variable-air-volume systems.
  - g. Settings for supply-air, static-pressure controller.
  - h. Other system operating conditions that affect performance.
- D. System Diagrams: Include schematic layouts of air and hydronic distribution systems. Present each system with single-line diagram and include the following:
  - 1. Quantities of outdoor, supply, return, and exhaust airflows.
  - 2. Water and steam flow rates.
  - 3. Duct, outlet, and inlet sizes.
  - 4. Pipe and valve sizes and locations.
  - 5. Terminal units.
  - 6. Balancing stations.
  - 7. Position of balancing devices.
- E. Air-Handling-Unit Test Reports: For air-handling units with coils, include the following:
  - 1. Unit Data:
    - a. Unit identification.
    - b. Location.
    - c. Make and type.
    - d. Model number and unit size.
    - e. Manufacturer's serial number.
    - f. Unit arrangement and class.
    - g. Discharge arrangement.
    - h. Sheave make, size in inches, and bore.
    - i. Center-to-center dimensions of sheave and amount of adjustments in inches.
    - j. Number, make, and size of belts.
    - k. Number, type, and size of filters.
  - 2. Motor Data:
    - a. Motor make, and frame type and size.
    - b. Horsepower and rpm.
    - c. Volts, phase, and hertz.

- d. Full-load amperage and service factor.
- e. Sheave make, size in inches, and bore.
- f. Center-to-center dimensions of sheave and amount of adjustments in inches.
- 3. Test Data (Indicated and Actual Values):
  - a. Total airflow rate in cfm.
  - b. Total system static pressure in inches wg.
  - c. Fan rpm.
  - d. Discharge static pressure in inches wg.
  - e. Filter static-pressure differential in inches wg.
  - f. Preheat-coil static-pressure differential in inches wg.
  - g. Cooling-coil static-pressure differential in inches wg.
  - h. Heating-coil static-pressure differential in inches wg.
  - i. Outdoor airflow in cfm.
  - j. Return airflow in cfm.
  - k. Outdoor-air damper position.
  - 1. Return-air damper position.
  - m. Vortex damper position.
- F. Apparatus-Coil Test Reports:
  - 1. Coil Data:
    - a. System identification.
    - b. Location.
    - c. Coil type.
    - d. Number of rows.
    - e. Fin spacing in fins per inch o.c.
    - f. Make and model number.
    - g. Face area in sq. ft..
    - h. Tube size in NPS.
    - i. Tube and fin materials.
    - j. Circuiting arrangement.
  - 2. Test Data (Indicated and Actual Values):
    - a. Airflow rate in cfm.
    - b. Average face velocity in fpm.
    - c. Air pressure drop in inches wg.
    - d. Outdoor-air, wet- and dry-bulb temperatures in deg F.
    - e. Return-air, wet- and dry-bulb temperatures in deg F.
    - f. Entering-air, wet- and dry-bulb temperatures in deg F.
    - g. Leaving-air, wet- and dry-bulb temperatures in deg F.
    - h. Water flow rate in gpm.
    - i. Water pressure differential in feet of head or psig.
    - j. Entering-water temperature in deg F.
    - k. Leaving-water temperature in deg F.
    - 1. Refrigerant expansion valve and refrigerant types.
    - m. Refrigerant suction pressure in psig.
    - n. Refrigerant suction temperature in deg F.

- o. Inlet steam pressure in psig.
- G. Gas- and Oil-Fired Heat Apparatus Test Reports: In addition to manufacturer's factory startup equipment reports, include the following:
  - 1. Unit Data:
    - a. System identification.
    - b. Location.
    - c. Make and type.
    - d. Model number and unit size.
    - e. Manufacturer's serial number.
    - f. Fuel type in input data.
    - g. Output capacity in Btu/h.
    - h. Ignition type.
    - i. Burner-control types.
    - j. Motor horsepower and rpm.
    - k. Motor volts, phase, and hertz.
    - 1. Motor full-load amperage and service factor.
    - m. Sheave make, size in inches, and bore.
    - n. Center-to-center dimensions of sheave and amount of adjustments in inches.
  - 2. Test Data (Indicated and Actual Values):
    - a. Total airflow rate in cfm.
    - b. Entering-air temperature in deg F.
    - c. Leaving-air temperature in deg F.
    - d. Air temperature differential in deg F.
    - e. Entering-air static pressure in inches wg.
    - f. Leaving-air static pressure in inches wg.
    - g. Air static-pressure differential in inches wg.
    - h. Low-fire fuel input in Btu/h.
    - i. High-fire fuel input in Btu/h.
    - j. Manifold pressure in psig.
    - k. High-temperature-limit setting in deg F.
    - 1. Operating set point in Btu/h.
    - m. Motor voltage at each connection.
    - n. Motor amperage for each phase.
    - o. Heating value of fuel in Btu/h.
- H. Electric-Coil Test Reports: For electric furnaces, duct coils, and electric coils installed in central-station air-handling units, include the following:
  - 1. Unit Data:
    - a. System identification.
    - b. Location.
    - c. Coil identification.
    - d. Capacity in Btu/h.
    - e. Number of stages.
    - f. Connected volts, phase, and hertz.

- g. Rated amperage.
- h. Airflow rate in cfm.
- i. Face area in sq. ft..
- j. Minimum face velocity in fpm.
- 2. Test Data (Indicated and Actual Values):
  - a. Heat output in Btu/h.
  - b. Airflow rate in cfm.
  - c. Air velocity in fpm.
  - d. Entering-air temperature in deg F.
  - e. Leaving-air temperature in deg F.
  - f. Voltage at each connection.
  - g. Amperage for each phase.
- I. Fan Test Reports: For supply, return, and exhaust fans, include the following:
  - 1. Fan Data:
    - a. System identification.
    - b. Location.
    - c. Make and type.
    - d. Model number and size.
    - e. Manufacturer's serial number.
    - f. Arrangement and class.
    - g. Sheave make, size in inches, and bore.
    - h. Center-to-center dimensions of sheave and amount of adjustments in inches.
  - 2. Motor Data:
    - a. Motor make, and frame type and size.
    - b. Horsepower and rpm.
    - c. Volts, phase, and hertz.
    - d. Full-load amperage and service factor.
    - e. Sheave make, size in inches, and bore.
    - f. Center-to-center dimensions of sheave, and amount of adjustments in inches.
    - g. Number, make, and size of belts.
  - 3. Test Data (Indicated and Actual Values):
    - a. Total airflow rate in cfm.
    - b. Total system static pressure in inches wg.
    - c. Fan rpm.
    - d. Discharge static pressure in inches wg.
    - e. Suction static pressure in inches wg.
- J. Round, Flat-Oval, and Rectangular Duct Traverse Reports: Include a diagram with a grid representing the duct cross-section and record the following:
  - 1. Report Data:

- a. System and air-handling-unit number.
- b. Location and zone.
- c. Traverse air temperature in deg F.
- d. Duct static pressure in inches wg.
- e. Duct size in inches.
- f. Duct area in sq. ft..
- g. Indicated airflow rate in cfm.
- h. Indicated velocity in fpm.
- i. Actual airflow rate in cfm.
- j. Actual average velocity in fpm.
- k. Barometric pressure in psig.
- K. Air-Terminal-Device Reports:
  - 1. Unit Data:
    - a. System and air-handling unit identification.
    - b. Location and zone.
    - c. Apparatus used for test.
    - d. Area served.
    - e. Make.
    - f. Number from system diagram.
    - g. Type and model number.
    - h. Size.
    - i. Effective area in sq. ft..
  - 2. Test Data (Indicated and Actual Values):
    - a. Airflow rate in cfm.
    - b. Air velocity in fpm.
    - c. Preliminary airflow rate as needed in cfm.
    - d. Preliminary velocity as needed in fpm.
    - e. Final airflow rate in cfm.
    - f. Final velocity in fpm.
    - g. Space temperature in deg F.
- L. System-Coil Reports: For reheat coils and water coils of terminal units, include the following:
  - 1. Unit Data:
    - a. System and air-handling-unit identification.
    - b. Location and zone.
    - c. Room or riser served.
    - d. Coil make and size.
    - e. Flowmeter type.
  - 2. Test Data (Indicated and Actual Values):
    - a. Airflow rate in cfm.
    - b. Entering-water temperature in deg F.

- c. Leaving-water temperature in deg F.
- d. Water pressure drop in feet of head or psig.
- e. Entering-air temperature in deg F.
- f. Leaving-air temperature in deg F.
- M. Pump Test Reports: Calculate impeller size by plotting the shutoff head on pump curves and include the following:
  - 1. Unit Data:
    - a. Unit identification.
    - b. Location.
    - c. Service.
    - d. Make and size.
    - e. Model number and serial number.
    - f. Water flow rate in gpm.
    - g. Water pressure differential in feet of head or psig.
    - h. Required net positive suction head in feet of head or psig.
    - i. Pump rpm.
    - j. Impeller diameter in inches.
    - k. Motor make and frame size.
    - l. Motor horsepower and rpm.
    - m. Voltage at each connection.
    - n. Amperage for each phase.
    - o. Full-load amperage and service factor.
    - p. Seal type.
  - 2. Test Data (Indicated and Actual Values):
    - a. Static head in feet of head or psig.
    - b. Pump shutoff pressure in feet of head or psig.
    - c. Actual impeller size in inches.
    - d. Full-open flow rate in gpm.
    - e. Full-open pressure in feet of head or psig.
    - f. Final discharge pressure in feet of head or psig.
    - g. Final suction pressure in feet of head or psig.
    - h. Final total pressure in feet of head or psig.
    - i. Final water flow rate in gpm.
    - j. Voltage at each connection.
    - k. Amperage for each phase.
- N. Instrument Calibration Reports:
  - 1. Report Data:
    - a. Instrument type and make.
    - b. Serial number.
    - c. Application.
    - d. Dates of use.
    - e. Dates of calibration.

# 3.8 VERIFICATION OF TAB REPORT

- A. The TAB specialist's test and balance engineer shall conduct the inspection in the presence of [Architect] [Owner] [Construction Manager] [commissioning authority].
- B. [Architect] [Owner] [Construction Manager] [Commissioning authority] shall randomly select measurements, documented in the final report, to be rechecked. Rechecking shall be limited to either 10 percent of the total measurements recorded or the extent of measurements that can be accomplished in a normal 8-hour business day.
- C. If rechecks yield measurements that differ from the measurements documented in the final report by more than the tolerances allowed, the measurements shall be noted as "FAILED."
- D. If the number of "FAILED" measurements is greater than 10 percent of the total measurements checked during the final inspection, the testing and balancing shall be considered incomplete and shall be rejected.
- E. If TAB work fails, proceed as follows:
  - 1. TAB specialists shall recheck all measurements and make adjustments. Revise the final report and balancing device settings to include all changes; resubmit the final report and request a second final inspection.
  - 2. If the second final inspection also fails, Owner may contract the services of another TAB specialist to complete TAB work according to the Contract Documents and deduct the cost of the services from the original TAB specialist's final payment.
  - 3. If the second verification also fails, **[Owner]** [design professional] [Architect] may contact AABC Headquarters regarding the AABC National Performance Guaranty.
- F. Prepare test and inspection reports.

# 3.9 ADDITIONAL TESTS

- A. Within 90 days of completing TAB, perform additional TAB to verify that balanced conditions are being maintained throughout and to correct unusual conditions.
- B. Seasonal Periods: If initial TAB procedures were not performed during near-peak summer and winter conditions, perform additional TAB during near-peak summer and winter conditions.

END OF SECTION 230593

## SECTION 230713 - DUCT INSULATION

## PART 1 - GENERAL

### 1.1 SUMMARY

- A. Section includes insulating the following duct services:
  - 1. Indoor, concealed supply and outdoor air.
  - 2. Indoor, exposed supply and outdoor air.
  - 3. Indoor, concealed return located in unconditioned space.
  - 4. Indoor, exposed return located in unconditioned space.
  - 5. Indoor, concealed, Type I, commercial, kitchen hood exhaust.
  - 6. Indoor, exposed, Type I, commercial, kitchen hood exhaust.
  - 7. Indoor, concealed oven and warewash exhaust.
  - 8. Indoor, exposed oven and warewash exhaust.
  - 9. Indoor, concealed exhaust between isolation damper and penetration of building exterior.
  - 10. Indoor, exposed exhaust between isolation damper and penetration of building exterior.
  - 11. Outdoor, concealed supply and return.
  - 12. Outdoor, exposed supply and return.

#### 1.2 DELIVERY, STORAGE, AND HANDLING

A. Packaging: Insulation material containers are to be marked with the manufacturer's name, appropriate ASTM standard designation, type and grade, and maximum use temperature.

#### 1.3 COORDINATION

- A. Coordinate sizes and locations of supports, hangers, and insulation shields specified in Section 230529 "Hangers and Supports for HVAC Piping and Equipment."
- B. Coordinate clearance requirements with duct Installer for duct insulation application. Before preparing ductwork Shop Drawings, establish and maintain clearance requirements for installation of insulation and field-applied jackets and finishes and for space required for maintenance.
- C. Coordinate installation and testing of heat tracing.

#### 1.4 SCHEDULING

A. Schedule insulation application after pressure testing systems and, where required, after installing and testing heat tracing. Insulation application may begin on segments that have satisfactory test results.

# PART 2 - PRODUCTS

#### 2.1 PERFORMANCE REQUIREMENTS

- A. Surface-Burning Characteristics: For insulation and related materials, as determined by testing identical products in accordance with ASTM E84, by a testing agency acceptable to authorities having jurisdiction. Factory label insulation, jacket materials, adhesive, mastic, tapes, and cement material containers with appropriate markings of applicable testing agency.
  - 1. [All Insulation Installed Indoors: Flame-spread index of 25 or less, and smoke-developed index of 50 or less.]
  - 2. [All Insulation Installed Indoors; Outdoors-Installed Insulation in Contact with Airstream: Flame-spread index of 25 or less, and smoke-developed index of 50 or less.]
  - 3. [All Insulation Installed Indoors and Outdoors: Flame-spread index of 25 or less, and smoke-developed index of 50 or less.]

#### PART 3 - EXECUTION

#### 3.1 EXAMINATION

- A. Examine substrates and conditions for compliance with requirements for installation tolerances and other conditions affecting performance of insulation application.
  - 1. Verify that systems to be insulated have been tested and are free of defects.
  - 2. Verify that surfaces to be insulated are clean and dry.
- B. Proceed with installation only after unsatisfactory conditions have been corrected.

#### 3.2 PREPARATION

A. Surface Preparation: Clean and dry surfaces to receive insulation. Remove materials that will adversely affect insulation application.

#### 3.3 GENERAL INSTALLATION REQUIREMENTS

- A. Install insulation materials, accessories, and finishes with smooth, straight, and even surfaces; free of voids throughout the length of ducts and fittings.
- B. Install insulation materials, vapor barriers or retarders, jackets, and thicknesses required for each item of duct system as specified in insulation system schedules.
- C. Install accessories compatible with insulation materials and suitable for the service. Install accessories that do not corrode, compress, or otherwise damage insulation or jacket.

- D. Install insulation with longitudinal seams at top and bottom of horizontal runs.
- E. Install multiple layers of insulation with longitudinal and end seams staggered.
- F. Keep insulation materials dry during application and finishing. Replace insulation materials that get wet during storage or in the installation process before being properly covered and sealed in accordance with Contract Documents[, unless otherwise approved by the engineer-of-record].
- G. Install insulation with tight longitudinal seams and end joints. Bond seams and joints with adhesive recommended by insulation material manufacturer.
- H. Install insulation with least number of joints practical.
- I. Where vapor barrier is indicated, seal joints, seams, and penetrations in insulation at hangers, supports, anchors, and other projections with vapor-barrier mastic.
  - 1. Install insulation continuously through hangers and around anchor attachments.
  - 2. For insulation application where vapor barriers are indicated, extend insulation on anchor legs from point of attachment to supported item to point of attachment to structure. Taper and seal ends at attachment to structure with vapor-barrier mastic.
  - 3. Install insert materials and install insulation to tightly join the insert. Seal insulation to insulation inserts with adhesive or sealing compound recommended by insulation material manufacturer.
- J. Apply adhesives, mastics, and sealants at manufacturer's recommended coverage rate and wet and dry film thicknesses.
- K. Install insulation with factory-applied jackets as follows:
  - 1. Draw jacket tight and smooth, but not to the extent of creating wrinkles or areas of compression in the insulation.
  - 2. Cover circumferential joints with 3-inch- wide strips, of same material as insulation jacket. Secure strips with adhesive and outward clinching staples along both edges of strip, spaced 4 inches o.c.
  - 3. Overlap jacket longitudinal seams at least 1-1/2 inches. Clean and dry surface to receive self-sealing lap. Staple laps with outward clinching staples along edge at [2 inches] [4 inches] o.c.
    - a. For below ambient services, apply vapor-barrier mastic over staples.
  - 4. Cover joints and seams with tape, according to insulation material manufacturer's written instructions, to maintain vapor seal.
  - 5. Where vapor barriers are indicated, apply vapor-barrier mastic on seams and joints and at ends adjacent to duct flanges and fittings.
- L. Cut insulation in a manner to avoid compressing insulation.
- M. Finish installation with systems at operating conditions. Repair joint separations and cracking due to thermal movement.

N. Repair damaged insulation facings by applying same facing material over damaged areas. Extend patches at least 4 inches beyond damaged areas. Adhere, staple, and seal patches similar to butt joints.

#### 3.4 PENETRATIONS

- A. Insulation Installation at Roof Penetrations: Install insulation continuously through roof penetrations.
  - 1. Seal penetrations with flashing sealant.
  - 2. For applications requiring only indoor insulation, terminate insulation above roof surface and seal with joint sealant. For applications requiring indoor and outdoor insulation, install insulation for outdoor applications tightly joined to indoor insulation ends. Seal joint with joint sealant.
  - 3. Extend jacket of outdoor insulation outside roof flashing at least 2 inches below top of roof flashing.
  - 4. Seal jacket to roof flashing with flashing sealant.
- B. Insulation Installation at Aboveground Exterior Wall Penetrations: Install insulation continuously through wall penetrations.
  - 1. Seal penetrations with flashing sealant.
  - 2. For applications requiring only indoor insulation, terminate insulation inside wall surface and seal with joint sealant. For applications requiring indoor and outdoor insulation, install insulation for outdoor applications tightly joined to indoor insulation ends. Seal joint with joint sealant.
  - 3. Extend jacket of outdoor insulation outside wall flashing and overlap wall flashing at least 2 inches.
  - 4. Seal jacket to wall flashing with flashing sealant.
- C. Insulation Installation at Interior Wall and Partition Penetrations (That Are Not Fire Rated): Install insulation continuously through walls and partitions.
- D. Insulation Installation at Fire-Rated Wall and Partition Penetrations: Terminate insulation at fire damper sleeves for fire-rated wall and partition penetrations. Externally insulate damper sleeves to match adjacent insulation and overlap duct insulation at least 2 inches.
  - 1. Comply with requirements in Section 078413 "Penetration Firestopping."
- E. Insulation Installation at Floor Penetrations:
  - 1. Duct: For penetrations through fire-rated assemblies, terminate insulation at fire damper sleeves and externally insulate damper sleeve beyond floor to match adjacent duct insulation. Overlap damper sleeve and duct insulation at least 2 inches.
  - 2. Seal penetrations through fire-rated assemblies. Comply with requirements in Section 078413 "Penetration Firestopping."

### 3.5 INSTALLATION OF FLEXIBLE ELASTOMERIC AND POLYOLEFIN INSULATION

- A. Comply with manufacturer's written installation instructions and ASTM C1710.
- B. Seal longitudinal seams and end joints with manufacturer's recommended adhesive to eliminate openings in insulation that allow passage of air to surface being insulated.
- C. Square and Rectangular Ducts and Plenums:
  - 1. Provide 1/4 inch more per side for a tight, compression fit.
  - 2. Cut sheet insulation with the following dimensions:
    - a. Width of duct plus 1/4 inch, one piece.
    - b. Height of duct plus 1/4 inch, plus thickness of insulation, two pieces.
    - c. Width of duct plus 1/4 inch, plus two times the thickness of insulation, one piece.
  - 3. Insulate the bottom of the duct with the sheet from (a) above, then the sides with the two sheets from (b) above, and finally the top of the duct with the sheet from (c) above.
  - 4. Insulation without self-adhering backing:
    - a. Apply 100 percent coverage of manufacturer adhesive on the metal surface, then the insulation, except for the last 1/4 inch where sheets will butt together.
    - b. Roll sheet down into position.
    - c. Press two sheets together under compression and apply adhesive at the butt joint to seal the two sheets together.
  - 5. Insulation with self-adhering backing:
    - a. Peel back release paper in 6- to 8-inch increments and line up sheet.
    - b. Press firmly to activate adhesive.
    - c. Align material and continue to line up correctly, pressing firmly while slowly removing release paper.
    - d. Allow 1/4-inch overlap for compression at butt joints.
    - e. Apply adhesive at the butt joint to seal the two sheets together.
  - 6. Insulate duct brackets following manufacturer's written installation instructions.
- D. Circular Ducts:
  - 1. Determine the circumference of the duct, using a strip of insulation the same thickness as to be used.
  - 2. Cut the sheet to the required size.
  - 3. Apply 100 percent coverage of manufacturer adhesive on the metal surface then the insulation.
  - 4. Apply manufacturer adhesive to the cut surfaces along 100 percent of the longitudinal seam. Press together the seam at the ends and then the middle. Close the entire seam starting from the middle.

### 3.6 INSTALLATION OF GLASS-FIBER AND MINERAL-WOOL INSULATION

- A. Blanket Insulation Installation on Ducts and Plenums: Secure with adhesive and insulation pins.
- B. Comply with manufacturer's written installation instructions.
  - 1. Apply adhesives according to manufacturer's recommended coverage rates per unit area, for [100] [50] <Insert number> percent coverage of duct and plenum surfaces.
  - 2. Apply adhesive to entire circumference of ducts and to all surfaces of fittings and transitions.
  - 3. Install either capacitor-discharge-weld pins and speed washers or cupped-head, capacitor-discharge-weld pins on sides and bottom of horizontal ducts and sides of vertical ducts as follows:
    - a. On duct sides with dimensions 18 inches and smaller, place pins along longitudinal centerline of duct. Space 3 inches maximum from insulation end joints, and 16 inches o.c.
    - b. On duct sides with dimensions larger than 18 inches, place pins 16 inches o.c. each way, and 3 inches maximum from insulation joints. Install additional pins to hold insulation tightly against surface at cross bracing.
    - c. Pins may be omitted from top surface of horizontal, rectangular ducts and plenums.
    - d. Do not overcompress insulation during installation.
    - e. Impale insulation over pins and attach speed washers.
    - f. Cut excess portion of pins extending beyond speed washers or bend parallel with insulation surface. Cover exposed pins and washers with tape matching insulation facing.
  - 4. For ducts and plenums with surface temperatures below ambient, install a continuous unbroken vapor barrier. Create a facing lap for longitudinal seams and end joints with insulation by removing 2 inches from one edge and one end of insulation segment. Secure laps to adjacent insulation section with 1/2-inch outward-clinching staples, 1 inch o.c. Install vapor barrier consisting of factory- or field-applied jacket, adhesive, vapor-barrier mastic, and sealant at joints, seams, and protrusions.
    - a. Repair punctures, tears, and penetrations with tape or mastic to maintain vapor-barrier seal.
    - b. Install vapor stops for ductwork and plenums operating below 50 deg F at 18-foot intervals. Vapor stops consist of vapor-barrier mastic applied in a Z-shaped pattern over insulation face, along butt end of insulation, and over the surface. Cover insulation face and surface to be insulated a width equal to two times the insulation thickness, but not less than 3 inches.
  - 5. Overlap unfaced blankets a minimum of 2 inches on longitudinal seams and end joints. At end joints, secure with steel bands spaced a maximum of 18 inches o.c.
  - 6. Install insulation on rectangular duct elbows and transitions with a full insulation section for each surface. Install insulation on round and flat-oval duct elbows with individually mitered gores cut to fit the elbow.

- 7. Insulate duct stiffeners, hangers, and flanges that protrude beyond insulation surface with 6-inch- wide strips of same material used to insulate duct. Secure on alternating sides of stiffener, hanger, and flange with pins spaced 6 inches o.c.
- C. Board Insulation Installation on Ducts and Plenums: Secure with adhesive and insulation pins.
  - 1. Apply adhesives according to manufacturer's recommended coverage rates per unit area, for [100] [50] <Insert number> percent coverage of duct and plenum surfaces.
  - 2. Apply adhesive to entire circumference of ducts and to all surfaces of fittings and transitions.
  - 3. Install either capacitor-discharge-weld pins and speed washers or cupped-head, capacitor-discharge-weld pins on sides and bottom of horizontal ducts and sides of vertical ducts as follows:
    - a. On duct sides with dimensions 18 inches and smaller, place pins along longitudinal centerline of duct. Space 3 inches maximum from insulation end joints, and 16 inches o.c.
    - b. On duct sides with dimensions larger than 18 inches, space pins 16 inches o.c. each way, and 3 inches maximum from insulation joints. Install additional pins to hold insulation tightly against surface at cross bracing.
    - c. Pins may be omitted from top surface of horizontal, rectangular ducts and plenums.
    - d. Do not overcompress insulation during installation.
    - e. Cut excess portion of pins extending beyond speed washers or bend parallel with insulation surface. Cover exposed pins and washers with tape matching insulation facing.
  - 4. For ducts and plenums with surface temperatures below ambient, install a continuous unbroken vapor barrier. Create a facing lap for longitudinal seams and end joints with insulation by removing 2 inches from one edge and one end of insulation segment. Secure laps to adjacent insulation section with 1/2-inch outward-clinching staples, 1 inch o.c. Install vapor barrier consisting of factory- or field-applied jacket, adhesive, vapor-barrier mastic, and sealant at joints, seams, and protrusions.
    - a. Repair punctures, tears, and penetrations with tape or mastic to maintain vapor-barrier seal.
    - b. Install vapor stops for ductwork and plenums operating below 50 deg F at 18-foot intervals. Vapor stops consist of vapor-barrier mastic applied in a Z-shaped pattern over insulation face, along butt end of insulation, and over the surface. Cover insulation face and surface to be insulated a width equal to two times the insulation thickness, but not less than 3 inches.
  - 5. Install insulation on rectangular duct elbows and transitions with a full insulation section for each surface. Groove and score insulation to fit as closely as possible to outside and inside radius of elbows. Install insulation on round and flat-oval duct elbows with individually mitered gores cut to fit the elbow.
  - 6. Insulate duct stiffeners, hangers, and flanges that protrude beyond insulation surface with 6-inch- wide strips of same material used to insulate duct. Secure on alternating sides of stiffener, hanger, and flange with pins spaced 6 inches o.c.

## 3.7 FINISHES

- A. Insulation with ASJ, Glass-Cloth, or Other Paintable Jacket Material: Paint jacket with paint system identified below and as specified in Section 099113 "Exterior Painting" and Section 099123 "Interior Painting."
  - 1. Flat Acrylic Finish: [**Two**] <**Insert number**> finish coats over a primer that is compatible with jacket material and finish coat paint. Add fungicidal agent to render fabric mildew proof.
    - a. Finish Coat Material: Interior, flat, latex-emulsion size.
- B. Color: Final color as selected by Architect. Vary first and second coats to allow visual inspection of the completed Work.
- C. Do not field paint aluminum or stainless steel jackets.

### 3.8 DUCT INSULATION SCHEDULE, GENERAL

- A. Plenums and Ducts Requiring Insulation:
  - 1. Indoor, concealed supply and outdoor air.
  - 2. Indoor, exposed supply and outdoor air.
  - 3. Indoor, concealed return located in unconditioned space.
  - 4. Indoor, exposed return located in unconditioned space.
  - 5. Indoor, concealed, Type I, commercial, kitchen hood exhaust.
  - 6. Indoor, exposed, Type I, commercial, kitchen hood exhaust.
  - 7. Indoor, concealed oven and warewash exhaust.
  - 8. Indoor, exposed oven and warewash exhaust.
  - 9. Indoor, concealed exhaust between isolation damper and penetration of building exterior.
  - 10. Indoor, exposed exhaust between isolation damper and penetration of building exterior.
  - 11. Outdoor, concealed supply and return.
  - 12. Outdoor, exposed supply and return.
- B. Items Not Insulated:
  - 1. Fibrous-glass ducts.
  - 2. Metal ducts with duct liner of sufficient thickness to comply with energy code and ASHRAE/IESNA 90.1.
  - 3. Factory-insulated flexible ducts.
  - 4. Factory-insulated plenums and casings.
  - 5. Flexible connectors.
  - 6. Vibration-control devices.
  - 7. Factory-insulated access panels and doors.
## 3.9 INDOOR DUCT AND PLENUM INSULATION SCHEDULE

- A. Concealed, Type I, Commercial, Kitchen Hood Exhaust Duct and Plenum Insulation: Fire-rated ; thickness as required to achieve 2-hour fire rating.
- B. Exposed, round and flat-oval, exhaust-air duct insulation is[ one of] the following:
  - 1. Polyolefin: [1 inch] **<Insert dimension>** thick.
- C. Exposed, Type I, Commercial, Kitchen Hood Exhaust Duct and Plenum Insulation: Fire-rated ; thickness as required to achieve 2-hour fire rating.

# 3.10 ABOVEGROUND, OUTDOOR DUCT AND PLENUM INSULATION SCHEDULE

- A. Concealed, rectangular, supply-air duct insulation is[ **one of**] the following:
  - 1. Glass-Fiber Board: [2 inches] [3 inches] <**Insert dimension**> thick and [2 lb/cu. ft.] [3 lb/cu. ft.] [6 lb/cu. ft.] nominal density.

# 3.11 INDOOR, FIELD-APPLIED JACKET SCHEDULE

- A. Install jacket over insulation material. For insulation with factory-applied jacket, install the field-applied jacket over the factory-applied jacket.
- B. If more than one material is listed, selection from materials listed is Contractor's option.
- C. Ducts and Plenums, Concealed:
  - 1. None.
  - 2. <Insert jacket type>.
- D. Ducts and Plenums, Exposed:
  - 1. None.
  - 2. **<Insert jacket type>**.

# 3.12 OUTDOOR, FIELD-APPLIED JACKET SCHEDULE

- A. Install jacket over insulation material. For insulation with factory-applied jacket, install the field-applied jacket over the factory-applied jacket.
- B. If more than one material is listed, selection from materials listed is Contractor's option.
- C. Ducts and Plenums, Concealed:
  - 1. None.
  - 2. **<Insert jacket type>**.

- D. Ducts and Plenums, Exposed, up to 48 Inches in Diameter or with Flat Surfaces up to 72 Inches:
  - 1. <**Insert jacket type**>.
- E. Ducts and Plenums, Exposed, Larger Than 48 Inches in Diameter or with Flat Surfaces Larger Than 72 Inches:
  - 1. **<Insert jacket type>**.

# SECTION 231123 - FACILITY NATURAL-GAS PIPING

## PART 1 - GENERAL

### 1.1 SUMMARY

- A. Section Includes:
  - 1. Pipes, tubes, and fittings.
  - 2. Manual gas shutoff valves.

### 1.2 DEFINITIONS

- A. CWP: Cold working pressure.
- B. Exposed, Interior Installations: Exposed to view indoors. Examples include finished occupied spaces and mechanical equipment rooms.
- C. Finished Spaces: Spaces other than mechanical and electrical equipment rooms, furred spaces, pipe and duct shafts, unheated spaces immediately below roof, spaces above ceilings, unexcavated spaces, crawlspaces, and tunnels.

### 1.3 ACTION SUBMITTALS

- A. Product Data:
  - 1. Piping specialties.
  - 2. Valves. Include pressure rating, capacity, settings, and electrical connection data of selected models.
  - 3. Dielectric fittings.

### 1.4 QUALITY ASSURANCE

- A. Steel Support Welding Qualifications: Qualify procedures and personnel in accordance with AWS D1.1/D1.1M, "Structural Welding Code Steel."
- B. Pipe Welding Qualifications: Qualify procedures and operators in accordance with the ASME Boiler and Pressure Vessel Code.

### 1.5 DELIVERY, STORAGE, AND HANDLING

A. Handling Flammable Liquids: Remove and dispose of liquids from existing natural-gas piping in accordance with requirements of authorities having jurisdiction.

- B. Deliver pipes and tubes with factory-applied end caps. Maintain end caps through shipping, storage, and handling to prevent pipe end damage and to prevent entrance of dirt, debris, and moisture.
- C. Store and handle pipes and tubes having factory-applied protective coatings to avoid damaging coating, and protect from direct sunlight.

### 1.6 PROJECT CONDITIONS

A. Perform site survey, research public utility records, and verify existing utility locations. Contact utility-locating service for area where Project is located.

### 1.7 COORDINATION

A. Coordinate requirements for piping identification for natural-gas piping. Comply with requirements in Section 220553 "Identification of Plumbing Piping and Equipment."

### PART 2 - PRODUCTS

### 2.1 SOURCE LIMITATIONS

A. Obtain each product type from single source from single manufacturer.

### 2.2 PERFORMANCE REQUIREMENTS

- A. Comply with the applicable Fuel Gas Code.
- B. Minimum Operating-Pressure Ratings:
  - 1. Piping and Valves: 100 psig minimum unless otherwise indicated.
- C. Natural-Gas System Pressure within Buildings:
  - 1. Single Pressure: 0.5 psig or less.
- D. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, by a qualified testing agency, and marked for intended location and application.

## 2.3 PIPES, TUBES, AND FITTINGS

- A. Steel Pipe: ASTM A53/A53M, black steel, Schedule 40, Type E or S, Grade B.
  - 1. Malleable-Iron Threaded Fittings: ASME B16.3, Class 150, standard pattern.
  - 2. Wrought-Steel Welding Fittings: ASTM A234/A234M for butt welding and socket welding.

### 2.4 PIPING SPECIALTIES

- A. Appliance Flexible Connectors:
  - 1. Indoor, Fixed-Appliance Flexible Connectors: Comply with ANSI Z21.24.
  - 2. Corrugated, stainless steel tubing with polymer coating.
  - 3. Operating-Pressure Rating: 0.5 psig.
  - 4. End Fittings: Zinc-coated steel.
  - 5. Threaded Ends: Comply with ASME B1.20.1.
  - 6. Maximum Length: 72 inches.
- B. Y-Pattern Strainers:
  - 1. Body: ASTM A126, Class B, cast iron with bolted cover and bottom drain connection.
  - 2. End Connections: Threaded ends for NPS 2 and smaller; flanged ends for NPS 2-1/2 and larger.
  - 3. Strainer Screen: 40-mesh startup strainer, and perforated stainless steel basket with 50 percent free area.
  - 4. CWP Rating: 125 psig.

## 2.5 JOINING MATERIALS

A. Welding Filler Metals: Comply with AWS D10.12/D10.12M for welding materials appropriate for wall thickness and chemical analysis of steel pipe being welded.

### 2.6 MANUAL GAS SHUTOFF VALVES

- A. General Requirements for Metallic Valves, NPS 2 and Smaller: Comply with ASME B16.33.
  - 1. CWP Rating: 125 psig.
  - 2. Threaded Ends: Comply with ASME B1.20.1.
  - 3. Dryseal Threads on Flare Ends: Comply with ASME B1.20.3.
  - 4. Listed and labeled by an NRTL acceptable to authorities having jurisdiction for valves 1 inch and smaller.
  - 5. Service Mark: Valves NPS 1-1/4 to NPS 2 having initials "WOG" permanently marked on valve body.
- B. General Requirements for Metallic Valves, NPS 2-1/2 and Larger: Comply with ASME B16.38.
  - 1. CWP Rating: 125 psig.
  - 2. Flanged Ends: Comply with ASME B16.5 for steel flanges.
  - 3. Service Mark: Initials "WOG" permanently marked on valve body.
- C. Two-Piece, Full-Port, Bronze Ball Valves with Bronze Trim: MSS SP-110.

- 1. Manufacturers: Subject to compliance with requirements, available manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
  - a. A.Y. McDonald Mfg. Co.
  - b. Apollo Valves; a part of Aalberts Integrated Piping Systems.
  - c. BrassCraft Manufacturing Co.; a Masco company.
- 2. Body: Bronze, complying with ASTM B584.
- 3. Ball: Chrome-plated bronze.
- 4. Stem: Bronze; blowout proof.
- 5. Seats: Reinforced TFE; blowout proof.
- 6. Packing: Threaded-body packnut design with adjustable-stem packing.
- 7. Ends: Threaded, flared, or socket as indicated in "Aboveground, Manual Gas Shutoff Valve Schedule" articles.
- 8. CWP Rating: 600 psig.
- 9. Listing: Valves NPS 1 and smaller are to be listed and labeled by an NRTL acceptable to authorities having jurisdiction.
- 10. Service: Suitable for natural-gas service with "WOG" indicated on valve body.
- D. Bronze Plug Valves: MSS SP-78.
  - 1. Manufacturers: Subject to compliance with requirements, available manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
    - a. A.Y. McDonald Mfg. Co.
    - b. Lee Brass Company.
  - 2. Body: Bronze, complying with ASTM B584.
  - 3. Plug: Bronze.
  - 4. Ends: Threaded, socket, or flanged as indicated in "Aboveground, Manual Gas Shutoff Valve Schedule" articles.
  - 5. Operator: Square head or lug type with tamperproof feature where indicated.
  - 6. Pressure Class: 125 psig.
  - 7. Listing: Valves NPS 1 and smaller are to be listed and labeled by an NRTL acceptable to authorities having jurisdiction.
  - 8. Service: Suitable for natural-gas service with "WOG" indicated on valve body.
- E. Cast-Iron, Lubricated Plug Valves: MSS SP-78.
  - 1. Manufacturers: Subject to compliance with requirements, available manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
    - a. A.Y. McDonald Mfg. Co.
    - b. Flowserve Corporation.
    - c. Mueller Co. LLC; Mueller Water Products, Inc.
  - 2. Body: Cast iron, complying with ASTM A126, Class B.

- 3. Plug: Bronze or nickel-plated cast iron.
- 4. Seat: Coated with thermoplastic.
- 5. Stem Seal: Compatible with natural gas.
- 6. Ends: Threaded or flanged as indicated in "Aboveground, Manual Gas Shutoff Valve Schedule" articles.
- 7. Operator: Square head or lug type with tamperproof feature where indicated.
- 8. Pressure Class: 125 psig.
- 9. Listing: Valves NPS 1 and smaller are to be listed and labeled by an NRTL acceptable to authorities having jurisdiction.
- 10. Service: Suitable for natural-gas service with "WOG" indicated on valve body.

## PART 3 - EXECUTION

## 3.1 EXAMINATION

- A. Examine roughing-in for natural-gas piping system to verify actual locations of piping connections before equipment installation.
- B. Proceed with installation only after unsatisfactory conditions have been corrected.

# 3.2 PREPARATION

- A. Close equipment shutoff valves before turning off natural gas to premises or piping section.
- B. Inspect natural-gas piping in accordance with the applicable Fuel Gas Code to determine that natural-gas utilization devices are turned off in piping section affected.
- C. Comply with the applicable Fuel Gas Code requirements for preventing accidental ignition.

# 3.3 INSTALLATION OF INDOOR PIPING

- A. Comply with the applicable Fuel Gas Code for installation and purging of natural-gas piping.
- B. Drawing plans, schematics, and diagrams indicate general location and arrangement of piping systems. Indicated locations and arrangements are used to size pipe and calculate friction loss, expansion, and other design considerations. Install piping as indicated unless deviations to layout are approved on Coordination Drawings.
- C. Arrange for pipe spaces, chases, slots, sleeves, and openings in building structure during progress of construction, to allow for mechanical installations.
- D. Do not install piping in concealed locations unless sleeved with the sleeve open at both ends.
- E. Install piping indicated to be exposed and piping in equipment rooms and service areas at right angles or parallel to building walls. Diagonal runs are prohibited unless specifically indicated otherwise.

- F. Where installing piping above accessible ceilings, allow sufficient space for ceiling panel removal.
- G. Locate valves for easy access. Do not locate valves within return air plenums.
- H. Install natural-gas piping at uniform grade of 2 percent down toward drip and sediment traps.
- I. Install piping free of sags and bends.
- J. Install fittings for changes in direction and branch connections.
- K. Verify final equipment locations for roughing-in.
- L. Comply with requirements in Sections specifying gas-fired appliances and equipment for roughing-in requirements.
- M. Drips and Sediment Traps: Install drips at points where condensate may collect, including service-meter outlets. Locate where accessible to permit cleaning and emptying. Do not install where condensate is subject to freezing.
  - 1. Construct drips and sediment traps using tee fitting with bottom outlet plugged or capped. Use nipple a minimum length of 3 pipe diameters, but not less than 3 inches long and same size as connected pipe. Install with space below bottom of drip to remove plug or cap.
  - 2. Install sediment trap on both sides of regulators for gas reduction to 2 psig with valve and cap.
- N. Conceal pipe installations in walls, pipe spaces, utility spaces, above ceilings, below grade or floors, and in floor channels unless indicated to be exposed to view.
- O. Concealed Location Installations: Except as specified below, install concealed natural-gas piping and piping installed under the building in containment conduit constructed of steel pipe with welded joints as described in Part 2. Install a vent pipe from containment conduit to outdoors and terminate with weatherproof vent cap.
  - 1. Above Accessible Ceilings: Natural-gas piping, fittings, valves, and regulators may be installed in accessible spaces without containment conduit.
  - 2. In Floors: Install natural-gas piping with welded or brazed joints and protective coating in cast-in-place concrete floors. Cover piping to be cast in concrete slabs with minimum of 1-1/2 inches of concrete. Piping may not be in physical contact with other metallic structures such as reinforcing rods or electrically neutral conductors. Do not embed piping in concrete slabs containing quick-set additives or cinder aggregate.
  - 3. In Floor Channels: Install natural-gas piping in floor channels. Channels must have cover and be open to space above cover for ventilation.
  - 4. In Walls or Partitions: Protect tubing installed inside partitions or hollow walls from physical damage using steel striker barriers at rigid supports.
    - a. Exception: Tubing passing through partitions or walls does not require striker barriers.

- 5. Prohibited Locations:
  - a. Do not install natural-gas piping in or through circulating air ducts, clothes or trash chutes, chimneys or gas vents (flues), ventilating ducts, or dumbwaiter or elevator shafts.
  - b. Do not install natural-gas piping in solid walls or partitions.
- P. Use eccentric reducer fittings to make reductions in pipe sizes. Install fittings with level side down.
- Q. Connect branch piping from top or side of horizontal piping.
- R. Install unions in pipes NPS 2 and smaller, adjacent to each valve, at final connection to each piece of equipment. Unions are not required at flanged connections.
- S. Do not use natural-gas piping as grounding electrode.
- T. Install sleeves for piping penetrations of walls, ceilings, and floors. Comply with requirements for sleeves specified in Section 230500 "Common Work Results for HVAC."
- U. Install sleeve seals for piping penetrations of concrete walls and slabs. Comply with requirements for sleeve seals specified in Section 230500 "Common Work Results for HVAC."
- V. Install escutcheons for piping penetrations of walls, ceilings, and floors. Comply with requirements for escutcheons specified in Section 230500 "Common Work Results for HVAC."

# 3.4 INSTALLATION OF VALVES

- A. Install manual gas shutoff valve for each gas appliance ahead of corrugated stainless steel tubing, aluminum, or copper connector.
- B. Do not install valves in return-air plenums.

# 3.5 PIPING JOINT CONSTRUCTION

- A. Ream ends of pipes and tubes and remove burrs.
- B. Remove scale, slag, dirt, and debris from inside and outside of pipe and fittings before assembly.
- C. Threaded Joints:
  - 1. Thread pipe with tapered pipe threads complying with ASME B1.20.1.
  - 2. Cut threads full and clean using sharp dies.
  - 3. Ream threaded pipe ends to remove burrs and restore full inside diameter of pipe.
  - 4. Apply appropriate tape or thread compound to external pipe threads unless dryseal threading is specified.
  - 5. Damaged Threads: Do not use pipe or pipe fittings with threads that are corroded or damaged. Do not use pipe sections that have cracked or open welds.

- D. Welded Joints:
  - 1. Construct joints in accordance with AWS D10.12/D10.12M, using qualified processes and welding operators.
  - 2. Bevel plain ends of steel pipe.
  - 3. Patch factory-applied protective coating as recommended by manufacturer at field welds and where damage to coating occurs during construction.

## 3.6 INSTALLATION OF HANGERS AND SUPPORTS

- A. Comply with requirements in Section 230529 "Hangers and Supports for HVAC Piping and Equipment" for hangers, supports, and anchor devices.
- B. Install hangers for steel piping, with maximum horizontal spacing and minimum rod diameters, to comply with MSS SP-58, locally enforced codes, and authorities having jurisdiction requirements, whichever are most stringent.
- C. Install hangers for corrugated stainless steel tubing, with maximum horizontal spacing and minimum rod diameters, to comply with manufacturer's written instructions, locally enforced codes, and authorities having jurisdiction requirements, whichever are most stringent.
- D. Support horizontal piping within 12 inches of each fitting.
- E. Support vertical runs of steel piping to comply with MSS SP-58, locally enforced codes, and authorities having jurisdiction requirements, whichever are most stringent.
- F. Support vertical runs of corrugated stainless steel tubing to comply with manufacturer's written instructions, locally enforced codes, and authorities having jurisdiction requirements, whichever are most stringent.

### 3.7 PIPING CONNECTIONS

- A. Connect to utility's gas main according to utility's procedures and requirements.
- B. Install natural-gas piping electrically continuous, and bonded to gas-appliance equipment grounding conductor of the circuit powering the appliance in accordance with NFPA 70.
- C. Where installing piping adjacent to appliances, allow space for service and maintenance of appliances.
- D. Connect piping to appliances using manual gas shutoff valves and unions. Install valve within 72 inches of each gas-fired appliance and equipment. Install union between valve and appliances or equipment.

### 3.8 FIELD QUALITY CONTROL

A. Tests and Inspections:

- 1. Test, inspect, and purge natural gas in accordance with the applicable Fuel Gas Code and authorities having jurisdiction.
- 2. Natural-gas piping will be considered defective if it does not pass tests and inspections.
- B. Prepare test and inspection reports.

## 3.9 ABOVEGROUND, MANUAL GAS SHUTOFF VALVE SCHEDULE

- A. Valves for pipe sizes NPS 2 and smaller are to be one of the following:
  - 1. Two-piece, full -port, bronze ball valves with bronze trim.
  - 2. Bronze plug valve.
- B. Valves for pipe sizes NPS 2-1/2 and larger are to be one of the following:
  - 1. Bronze plug valve.
  - 2. Cast-iron, lubricated plug valve.

## SECTION 233113 - METAL DUCTS

## PART 1 - GENERAL

## 1.1 DEFINITIONS

A. OSHPD: Office of Statewide Health Planning and Development (State of California).

## PART 2 - PRODUCTS

### 2.1 PERFORMANCE REQUIREMENTS

- A. Structural Performance: Duct hangers and supports[ and seismic restraints] are to withstand the effects of gravity[ and seismic] loads and stresses within limits and under conditions described in SMACNA's "HVAC Duct Construction Standards Metal and Flexible" [and] [ASCE/SEI 7] <Insert applicable building code>. [Seismically brace duct hangers and supports in accordance with] [SMACNA's "Seismic Restraint Manual: Guidelines for Mechanical Systems."] [SMACNA's "Seismic Restraint Manual: Guidelines for Mechanical Systems OSHPD Edition."] <Insert reference document.>
  - 1. Seismic Hazard Level (SHL): [AA] [A] [B] [C] [D].
  - 2. Connection Level: [1] [2].
  - 3. **<Insert requirement>**.
- B. Seismic Performance: Ductwork to withstand the effects of earthquake motions determined in accordance with [ASCE/SEI 7] <Insert requirement>. See Section 230548 "Vibration and Seismic Controls for HVAC."
  - 1. The term "withstand" means "the unit will remain in place without separation of any parts from the device when subjected to the seismic forces specified[ and the unit will be fully operational after the seismic event]."
  - 2. Component Importance Factor: [1.5] [1.0].
  - 3. <Insert requirements for Component Amplification Factor and Component Response Modification Factor>.
- C. Wind Performance: Ducts are to withstand the effects of wind determined in accordance with to [ASCE/SEI 7] <Insert requirement>. See Section 230548 "Vibration and Seismic Controls for HVAC."
- D. Airstream Surfaces: Surfaces in contact with airstream comply with requirements in ASHRAE 62.1.
- E. ASHRAE Compliance: Applicable requirements in ASHRAE 62.1, Section 5 "Systems and Equipment," and Section 7 "Construction and System Startup."

- F. ASHRAE/IES Compliance: Applicable requirements in ASHRAE/IES 90.1, Section 6.4.4 -"HVAC System Construction and Insulation."
- G. Duct Dimensions: Unless otherwise indicated, all duct dimensions indicated on Drawings are inside clear dimensions and do not include insulation or duct wall thickness.

### PART 3 - EXECUTION

### 3.1 DUCT INSTALLATION

- A. Drawing plans, schematics, and diagrams indicate general location and arrangement of duct system. Indicated duct locations, configurations, and arrangements were used to size ducts and calculate friction loss for air-handling equipment sizing and for other design considerations. Install duct systems as indicated unless deviations to layout are approved on Shop Drawings and coordination drawings.
- B. Install ducts in accordance with SMACNA's "HVAC Duct Construction Standards Metal and Flexible" unless otherwise indicated.
- C. Install ducts in maximum practical lengths with fewest possible joints.
- D. Install factory- or shop-fabricated fittings for changes in direction, size, and shape and for branch connections.
- E. Unless otherwise indicated, install ducts vertically and horizontally, and parallel and perpendicular to building lines.
- F. Install ducts close to walls, overhead construction, columns, and other structural and permanent enclosure elements of building.
- G. Install ducts with a clearance of 1 inch, plus allowance for insulation thickness.
- H. Route ducts to avoid passing through transformer vaults and electrical equipment rooms and enclosures.
- I. Where ducts pass through non-fire-rated interior partitions and exterior walls and are exposed to view, cover the opening between the partition and duct or duct insulation with sheet metal flanges of same metal thickness as the duct. Overlap openings on four sides by at least 1-1/2 inches.
- J. Install fire[, combination fire/smoke,] and smoke dampers where indicated on Drawings and as required by code, and by local authorities having jurisdiction. Comply with requirements in Section 233300 "Air Duct Accessories" for fire and smoke dampers and specific installation requirements of the damper UL listing.
- K. Install heating coils, cooling coils, air filters, dampers, and all other duct-mounted accessories in air ducts where indicated on Drawings.

- L. Protect duct interiors from moisture, construction debris and dust, and other foreign materials both before and after installation.[ Comply with SMACNA's "IAQ Guidelines for Occupied Buildings Under Construction," Appendix G, "Duct Cleanliness for New Construction Guidelines."]
- M. Elbows: Use long-radius elbows wherever they fit.
  - 1. Fabricate 90-degree rectangular mitered elbows to include turning vanes.
  - 2. Fabricate 90-degree round elbows with a minimum of three segments for 12 inches and smaller and a minimum of five segments for 14 inches and larger.
- N. Branch Connections: Use lateral or conical branch connections.

## 3.2 INSTALLATION OF EXPOSED DUCTWORK

- A. Protect ducts exposed in finished spaces from being dented, scratched, or damaged.
- B. Trim duct sealants flush with metal. Create a smooth and uniform exposed bead. Do not use two-part tape sealing system.
- C. Grind welds to provide smooth surface free of burrs, sharp edges, and weld splatter. When welding stainless steel with a No. 3 or 4 finish, grind the welds flush, polish the exposed welds, and treat the welds to remove discoloration caused by welding.
- D. Maintain consistency, symmetry, and uniformity in arrangement and fabrication of fittings, hangers and supports, duct accessories, and air outlets.
- E. Repair or replace damaged sections and finished work that does not comply with these requirements.

# 3.3 ADDITIONAL INSTALLATION REQUIREMENTS FOR TYPE 1 COMMERCIAL KITCHEN GREASE HOOD EXHAUST DUCT

- A. Install ducts in accordance with NFPA 96, "Ventilation Control and Fire Protection of Commercial Cooking Operation"; SMACNA's "HVAC Duct Construction Standards - Metal and Flexible"; and SMACNA's "Kitchen Ventilation Systems and Food Service Equipment Fabrication and Installation Guidelines" unless otherwise indicated.
- B. Install all ducts without dips and traps that may hold grease, and sloped a minimum of 2 percent to drain grease back to the hood.
- C. All ducts exposed to view are to be constructed of stainless steel as per "Duct Schedule" Article. All ducts concealed from view are to be [**stainless**] [**carbon**] steel as per "Duct Schedule" Article.
- D. All joints are to be welded and are to be telescoping, bell, or flange joint as per NFPA 96.

- E. Install fire-rated access panel assemblies at each change in direction and at maximum intervals of [20] [12] <**Insert dimension**> feet in horizontal ducts, and at every floor for vertical ducts, or as indicated on Drawings.
- F. Do not penetrate fire-rated assemblies except as allowed by applicable building codes and authorities having jurisdiction.

# 3.4 ADDITIONAL INSTALLATION REQUIREMENTS FOR EXHAUST DUCTS SERVING COMMERCIAL DISHWASHERS AND OTHER HIGH-HUMIDITY LOCATIONS

- A. Install dishwasher exhaust ducts and other exhaust ducts from wet, high-humidity locations without dips and traps that may hold water. Slope ducts a minimum of 2 percent back to dishwasher or toward drain.
- B. Provide a drain pocket at each low point and at the base of each riser with a 1-inch trapped copper drain from each drain pocket to open site floor drain.
- C. Minimize number of transverse seams.
- D. Do not locate longitudinal seams on bottom of duct.

# 3.5 ADDITIONAL INSTALLATION REQUIREMENTS FOR LABORATORY EXHAUST AND FUME HOOD EXHAUST DUCTS

- A. Install ducts in accordance with NFPA 45, "Fire Protection for Laboratories Using Chemicals."
- B. Install exhaust ducts without dips and traps that may hold water. Slope ducts a minimum of 2 percent back to hood or inlet. Where indicated on Drawings, install trapped drain piping.
- C. Connect duct to fan, fume hood, and other equipment indicated on Drawings.

### 3.6 DUCTWORK EXPOSED TO WEATHER

- A. All external joints are to [**be welded**] [**have secure watertight mechanical connections**]. Seal all openings to provide weatherproof construction.
- B. Construct ductwork to resist external loads of wind, snow, ice, and other effects of weather. Provide necessary supporting structures.
- C. Single Wall:
  - 1. Ductwork is to be [**Type 304**] [**Type 316**] stainless steel.
  - 2. Ductwork is to be galvanized steel.
    - a. If duct outer surface is uninsulated, protect outer surface with suitable paint. Paint materials and application requirements are specified in Section 099113 "Exterior Painting."

- 3. Where ducts have external insulation, provide weatherproof aluminum jacket. See Section 230713 "Duct Insulation."
- D. Double Wall:
  - 1. Ductwork complies with requirements in "Double-Wall Rectangular Ducts and Fittings" or "Double-Wall Round [and Flat-Oval ]Ducts and Fittings" Article.
  - 2. Ductwork outer wall is to be [**Type 304**] [**Type 316**] stainless steel indicated by manufacturer to be suitable for outdoor installation.
  - 3. Provide interstitial insulation.

### 3.7 DUCT SEALING

- A. Seal ducts for duct static-pressure, seal classes, and leakage classes specified in "Duct Schedule" Article in accordance with SMACNA's "HVAC Duct Construction Standards -Metal and Flexible."
- B. Seal ducts at a minimum to the following seal classes in accordance with SMACNA's "HVAC Duct Construction Standards Metal and Flexible":
  - 1. Comply with SMACNA's "HVAC Duct Construction Standards Metal and Flexible."
  - 2. Outdoor, Supply-Air Ducts: Seal Class A.
  - 3. Outdoor, Exhaust Ducts: Seal Class C.
  - 4. Outdoor, Return-Air Ducts: Seal Class C.
  - 5. Unconditioned Space, Supply-Air Ducts in Pressure Classes 2-Inch wg and Lower: Seal Class B.
  - 6. Unconditioned Space, Supply-Air Ducts in Pressure Classes Higher Than 2-Inch wg: Seal Class A.
  - 7. Unconditioned Space, Exhaust Ducts: Seal Class C.
  - 8. Unconditioned Space, Return-Air Ducts: Seal Class B.
  - 9. Conditioned Space, Supply-Air Ducts in Pressure Classes 2-Inch wg and Lower: Seal Class C.
  - 10. Conditioned Space, Supply-Air Ducts in Pressure Classes Higher Than 2-Inch wg: Seal Class B.
  - 11. Conditioned Space, Exhaust Ducts: Seal Class B.
  - 12. Conditioned Space, Return-Air Ducts: Seal Class C.

### 3.8 SEISMIC-RESTRAINT-DEVICE INSTALLATION

A. See Section 230548 "Vibration and Seismic Controls for HVAC" for seismic restraint installation requirements.

### 3.9 DUCTWORK CONNECTIONS

A. Make connections to equipment with flexible connectors complying with Section 233300 "Air Duct Accessories."

B. Comply with SMACNA's "HVAC Duct Construction Standards - Metal and Flexible" for branch, outlet and inlet, and terminal unit connections.

### 3.10 PAINTING

Paint interior of metal ducts that are visible through registers and grilles and that do not have duct liner. Apply one coat of flat, black, latex paint over a compatible galvanized-steel primer. Paint materials and application requirements are specified in Section 099113 "Exterior Painting" and Section 099123 "Interior Painting."

### 3.11 DUCT CLEANING

- A. Clean new duct system(s) before testing, adjusting, and balancing.
- B. For cleaning of existing ductwork, see Section 230130.52 "Existing HVAC Air Distribution System Cleaning."
- C. Use duct cleaning methodology as indicated in NADCA ACR.
- D. Use service openings for entry and inspection.
  - 1. Provide openings with access panels appropriate for duct static-pressure and leakage class at dampers, coils, and any other locations where required for inspection and cleaning access. Provide insulated panels for insulated or lined duct. Patch insulation and liner as recommended by duct liner manufacturer. Comply with Section 233300 "Air Duct Accessories" for access panels and doors.
  - 2. Disconnect and reconnect flexible ducts as needed for cleaning and inspection.
  - 3. Remove and reinstall ceiling to gain access during the cleaning process.
- E. Particulate Collection and Odor Control:
  - 1. When venting vacuuming system inside the building, use HEPA filtration with 99.97 percent collection efficiency for 0.3-micron-size (or larger) particles.
  - 2. When venting vacuuming system to outdoors, use filter to collect debris removed from HVAC system, and locate exhaust downwind and away from air intakes and other points of entry into building.
- F. Clean the following components by removing surface contaminants and deposits:
  - 1. Air outlets and inlets (registers, grilles, and diffusers).
  - 2. Supply, return, and exhaust fans including fan housings, plenums (except ceiling supply and return plenums), scrolls, blades or vanes, shafts, baffles, dampers, and drive assemblies.
  - 3. Air-handling unit internal surfaces and components including mixing box, coil section, air wash systems, spray eliminators, condensate drain pans, humidifiers and dehumidifiers, filters and filter sections, and condensate collectors and drains.
  - 4. Coils and related components.

- 5. Return-air ducts, dampers, actuators, and turning vanes except in ceiling plenums and mechanical equipment rooms.
- 6. Supply-air ducts, dampers, actuators, and turning vanes.
- 7. Dedicated exhaust and ventilation components and makeup air systems.
- G. Mechanical Cleaning Methodology:
  - 1. Clean metal duct systems using mechanical cleaning methods that extract contaminants from within duct systems and remove contaminants from building.
  - 2. Use vacuum-collection devices that are operated continuously during cleaning. Connect vacuum device to downstream end of duct sections so areas being cleaned are under negative pressure.
  - 3. Use mechanical agitation to dislodge debris adhered to interior duct surfaces without damaging integrity of metal ducts, duct liner, or duct accessories.
  - 4. Clean fibrous-glass duct liner with HEPA vacuuming equipment; do not permit duct liner to get wet. Replace fibrous-glass duct liner that is damaged, deteriorated, or delaminated or that has friable material, mold, or fungus growth.
  - 5. Clean coils and coil drain pans in accordance with NADCA ACR. Keep drain pan operational. Rinse coils with clean water to remove latent residues and cleaning materials; comb and straighten fins.
  - 6. Provide drainage and cleanup for wash-down procedures.
  - 7. Antimicrobial Agents and Coatings: Apply EPA-registered antimicrobial agents if fungus is present. Apply antimicrobial agents in accordance with manufacturer's written instructions after removal of surface deposits and debris.

### 3.12 STARTUP

A. Air Balance: Comply with requirements in Section 230593 "Testing, Adjusting, and Balancing for HVAC."

### 3.13 DUCT SCHEDULE

- A. Fabricate ducts with galvanized sheet steel except as otherwise indicated and as follows:
  - 1. Fabricate all ducts to achieve SMACNA pressure class, seal class, and leakage class as indicated below.
  - 2. Underground Ducts: Concrete-encased, [galvanized sheet steel] [PVC-coated, galvanized sheet steel with thicker coating on duct exterior] [stainless steel].
  - 3. <Insert requirements>.
- B. Supply Ducts:
  - 1. Ducts Connected to Fan Coil Units, Furnaces, Heat Pumps, and Terminal Units <Insert equipment>:
    - a. Pressure Class: Positive [1-] [2-] **<Insert number**>inch wg.
    - b. Minimum SMACNA Seal Class: [A] [B] [C].
    - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
    - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].

- 2. Ducts Connected to Constant-Volume Air-Handling Units < Insert equipment>:
  - a. Pressure Class: Positive [2-] [3-] **<Insert number**>inch wg.
  - b. Minimum SMACNA Seal Class: [A] [B].
  - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
  - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- 3. Ducts Connected to Variable-Air-Volume Air-Handling Units < Insert equipment>:
  - a. Pressure Class: Positive [3-] [4-] **<Insert number**>inch wg.
  - b. Minimum SMACNA Seal Class: [A] [B].
  - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
  - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- 4. Ducts Connected to Equipment Not Listed Above:
  - a. Pressure Class: Positive [2-] [3-] [4-] **<Insert number**>inch wg.
  - b. Minimum SMACNA Seal Class: [A] [B] [C].
  - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
  - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- C. Return Ducts:
  - 1. Ducts Connected to Fan Coil Units, Furnaces, Heat Pumps, and Terminal Units <Insert equipment>:
    - a. Pressure Class: Positive or negative [1-] [2-] **<Insert number**>inch wg.
    - b. Minimum SMACNA Seal Class: [A] [B] [C].
    - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
    - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
  - 2. Ducts Connected to Air-Handling Units <**Insert equipment**>:
    - a. Pressure Class: Positive or negative [2-] [3-] **<Insert number**>inch wg.
    - b. Minimum SMACNA Seal Class: [A] [B] [C].
    - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
    - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
  - 3. Ducts Connected to Equipment Not Listed above:
    - a. Pressure Class: Positive or negative [2-] [3-] [4-] **<Insert number**>inch wg.
    - b. Minimum SMACNA Seal Class: [A] [B] [C].
    - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
    - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- D. Exhaust Ducts:
  - 1. Ducts Connected to Fans Exhausting (ASHRAE 62.1, Class 1 and 2) Air:
    - a. Pressure Class: Negative [1-] [2-] [3-] **<Insert number**>inch wg.

- b. Minimum SMACNA Seal Class: [A] [B] [C] if negative pressure, and A if positive pressure.
- c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
- d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- 2. Ducts Connected to Air-Handling Units <**Insert equipment**>:
  - a. Pressure Class: Positive or negative [2-] [3-] **<Insert number**>inch wg.
  - b. Minimum SMACNA Seal Class: [A] [B] [C] if negative pressure, and [A] [B] [C] if positive pressure.
  - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
  - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- 3. Ducts Connected to Commercial Kitchen Hoods: Comply with NFPA 96.
  - a. Exposed to View: Type 304, stainless steel sheet, [No. 4] [No. 3] <Insert finish> finish.
  - b. Concealed: [Type 304, stainless steel sheet, No. 2D finish] [Carbon-steel sheet].
  - c. Welded seams and joints.
  - d. Pressure Class: Positive or negative [2-] [3-] [4-] <**Insert number**>inch wg.
  - e. Airtight/watertight.
- 4. Ducts Connected to Dishwashers, Dishwasher Hoods, and Other High-Humidity Locations:
  - a. Type 304, stainless steel sheet.
  - b. Exposed to View: [No. 4] [No. 3] <Insert finish> finish.
  - c. Concealed: [No. 2D] <Insert finish> finish.
  - d. Welded longitudinal seams; welded or flanged transverse joints with watertight EPDM gaskets.
  - e. Pressure Class: Positive or negative [2-] [3-] <**Insert number**>inch wg.
  - f. Airtight/watertight.
- 5. Ducts Connected to Fans Exhausting Fume Hood, Laboratory, and Process (ASHRAE 62.1, Class 3 and Class 4) Air:
  - a. [Type 316] [Type 304], stainless steel sheet.
    - 1) Exposed to View: [No. 4] [No. 3] <Insert finish> finish.
    - 2) Concealed: [No. 2B] [No. 2D] <Insert finish> finish.
  - b. PVC-coated, galvanized sheet steel with thicker coating on duct interior.
  - c. Pressure Class: Positive or negative [3-] [4-] [6-] **<Insert number**>inch wg.
  - d. [Minimum SMACNA Seal Class A] [Welded seams and joints].
  - e. [SMACNA Leakage Class 2.]
  - f. [Airtight/watertight.]
- 6. Ducts Connected to Equipment Not Listed above:
  - a. Pressure Class: Positive or negative [2-] [3-] [4-] **<Insert number**>inch wg.

- b. Minimum SMACNA Seal Class: [A] [B] if negative pressure; A if positive pressure.
- c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
- d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- E. Outdoor-Air (Not Filtered, Heated, or Cooled) Ducts:
  - 1. Ducts Connected to Fan Coil Units, Furnaces, Heat Pumps, and Terminal Units <Insert equipment>:
    - a. Pressure Class: Positive or negative [1-] [2-] <**Insert number**>inch wg.
    - b. Minimum SMACNA Seal Class: [A] [B] [C].
    - c. SMACNA Leakage Class for Rectangular: [8] [16].
    - d. SMACNA Leakage Class for Round and Flat Oval: [8] [16].
  - 2. Ducts Connected to Air-Handling Units <Insert equipment>:
    - a. Pressure Class: Positive or negative [2-] [3-] <**Insert number**>inch wg.
    - b. Minimum SMACNA Seal Class: [A] [B].
    - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
    - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
  - 3. Ducts Connected to Equipment Not Listed Above:
    - a. Pressure Class: Positive or negative [2-] [3-] [4-] **<Insert number**>inch wg.
    - b. Minimum SMACNA Seal Class: [A] [B].
    - c. SMACNA Leakage Class for Rectangular: [2] [4] [8] [16].
    - d. SMACNA Leakage Class for Round and Flat Oval: [2] [4] [8] [16].
- F. Intermediate Reinforcement:
  - 1. Galvanized-Steel Ducts: [Galvanized steel] [Carbon steel coated with zinc-chromate primer] [Galvanized steel or carbon steel coated with zinc-chromate primer].
  - 2. PVC-Coated Ducts:
    - a. Exposed to Airstream: Match duct material.
    - b. Not Exposed to Airstream: [Galvanized] [Match duct material].
  - 3. Stainless Steel Ducts:
    - a. Exposed to Airstream: Match duct material.
    - b. Not Exposed to Airstream: [Galvanized] [Match duct material].
  - 4. Aluminum Ducts: [Aluminum] [or] [galvanized steel coated with zinc chromate].
- G. Liner:
  - 1. Supply-Air Ducts: , [5/8] [1] [1-1/2] [2] **<Insert dimension**> inch thick.
  - 2. Return-Air Ducts: , [5/8] [1] [1-1/2] [2] **<Insert dimension**> inch thick.
  - 3. Exhaust-Air Ducts: , [5/8] [1] **<Insert dimension**> inch thick.
  - 4. Supply Fan Plenums: , [5/8] [1] [1-1/2] [2] **<Insert dimension**> inch thick.

- 5. Return- and Exhaust-Fan Plenums: , [5/8] [1] [1-1/2] [2] **<Insert dimension**> inches thick.
- 6. Transfer Ducts: , [5/8] [1] [1-1/2] [2] **<Insert dimension>** inch thick.
- H. Double-Wall Duct Interstitial Insulation:
  - 1. Supply-Air Ducts: [1] [1-1/2] [2] **<Insert dimension>** inch thick.
  - 2. Return-Air Ducts: [1] [1-1/2] [2] **<Insert dimension>** inch thick.
  - 3. Exhaust-Air Ducts: [1] [1-1/2] [2] **<Insert dimension>** inch thick.
- I. Elbow Configuration:
  - 1. Rectangular Duct Requirements for Different Velocities: Comply with SMACNA's "HVAC Duct Construction Standards - Metal and Flexible," Figure 4-2, "Rectangular Elbows."
    - a. Velocity 1000 fpm or Lower:
      - 1) Radius Type RE 1 with minimum 0.5 radius-to-diameter ratio.
      - 2) Mitered Type RE 4 without vanes.
    - b. Velocity 1000 to 1500 fpm:
      - 1) Radius Type RE 1 with minimum 1.0 radius-to-diameter ratio.
      - 2) Radius Type RE 3 with minimum 0.5 radius-to-diameter ratio and two vanes.
      - 3) Mitered Type RE 2 with vanes complying with SMACNA's "HVAC Duct Construction Standards - Metal and Flexible," Figure 4-3, "Vanes and Vane Runners," and Figure 4-4, "Vane Support in Elbows."
    - c. Velocity 1500 fpm or Higher:
      - 1) Radius Type RE 1 with minimum 1.5 radius-to-diameter ratio.
      - 2) Radius Type RE 3 with minimum 1.0 radius-to-diameter ratio and two vanes.
      - 3) Mitered Type RE 2 with vanes complying with SMACNA's "HVAC Duct Construction Standards - Metal and Flexible," Figure 4-3, "Vanes and Vane Runners," and Figure 4-4, "Vane Support in Elbows."
  - 2. Rectangular Duct Requirements for All Velocities: Comply with SMACNA's "HVAC Duct Construction Standards Metal and Flexible," Figure 4-2, "Rectangular Elbows."
    - a. Radius Type RE 1 with minimum 1.5 radius-to-diameter ratio.
    - b. Radius Type RE 3 with minimum 1.0 radius-to-diameter ratio and two vanes.
    - c. Mitered Type RE 2 with vanes complying with SMACNA's "HVAC Duct Construction Standards - Metal and Flexible," Figure 4-3, "Vanes and Vane Runners," and Figure 4-4, "Vane Support in Elbows."
  - 3. Round Duct: Comply with SMACNA's "HVAC Duct Construction Standards Metal and Flexible," Figure 3-4, "Round Duct Elbows."

- Minimum Radius-to-Diameter Ratio and Elbow Segments: Comply with SMACNA's "HVAC Duct Construction Standards - Metal and Flexible," Table 3-1, "Mitered Elbows." Elbows with less than 90-degree change of direction have proportionately fewer segments.
  - 1) Velocity 1000 fpm or Lower: 0.5 radius-to-diameter ratio and three segments for 90-degree elbow.
  - 2) Velocity 1000 to 1500 fpm: 1.0 radius-to-diameter ratio and four segments for 90-degree elbow.
  - 3) Velocity 1500 fpm or Higher: 1.5 radius-to-diameter ratio and five segments for 90-degree elbow.
  - 4) Radius-to Diameter Ratio: 1.5.
- b. Round Elbows, [12] **<Insert dimension**> Inches and Smaller in Diameter: Stamped or pleated.
- c. Round Elbows, [14] <Insert dimension> Inches and Larger in Diameter: [Standing seam] [Welded].
- J. Branch Configuration:
  - 1. Rectangular Duct: Comply with SMACNA's "HVAC Duct Construction Standards -Metal and Flexible," Figure 4-6, "Branch Connection."
    - a. Rectangular Main to Rectangular Branch: 45-degree entry.
    - b. Rectangular Main to Round Branch: Conical spin in.
  - 2. Round and Flat Oval: Comply with SMACNA's "HVAC Duct Construction Standards -Metal and Flexible," Figure 3-5, "90 Degree Tees and Laterals," and Figure 3-6, "Conical Tees." Saddle taps are permitted in existing duct.
    - a. Velocity 1000 fpm or Lower: 90-degree tap.
    - b. Velocity 1000 to 1500 fpm: Conical tap.
    - c. Velocity 1500 fpm or Higher: 45-degree lateral.

## SECTION 233300 - AIR DUCT ACCESSORIES

PART 1 - GENERAL

## PART 2 - PRODUCTS

### 2.1 MATERIALS

- A. Galvanized Sheet Steel: Comply with ASTM A653/A653M.
  - 1. Galvanized Coating Designation: [G60] [G90].
  - 2. Exposed-Surface Finish: Mill phosphatized.
- B. Stainless Steel Sheets: Comply with ASTM A480/A480M, Type 304, and having a [No. 2] <Insert finish designation> finish for concealed ducts and <Insert finish designation> finish for exposed ducts.
- C. Aluminum Sheets: Comply with ASTM B209/B209M, Alloy 3003, Temper H14; with mill finish for concealed ducts and standard, one-side bright finish for exposed ducts.
- D. Extruded Aluminum: Comply with ASTM B221, Alloy 6063, Temper T6.
- E. Reinforcement Shapes and Plates: Galvanized-steel reinforcement where installed on galvanized sheet metal ducts; compatible materials for aluminum and stainless steel ducts.
- F. Tie Rods: Galvanized steel, [1/4-inch] **<Insert dimension**> minimum diameter for lengths 36 inches or less; [3/8-inch] **<Insert dimension**> minimum diameter for lengths longer than 36 inches.

PART 3 - EXECUTION

SECTION 233346 - FLEXIBLE DUCTS

PART 1 - GENERAL (Not Applicable)

PART 2 - PRODUCTS (Not Applicable)

PART 3 - EXECUTION (Not Applicable)

SECTION 233423 - HVAC POWER VENTILATORS

PART 1 - GENERAL (Not Applicable)

PART 2 - PRODUCTS (Not Applicable)

PART 3 - EXECUTION (Not Applicable)

## SECTION 233713.23 - REGISTERS AND GRILLES

PART 1 - GENERAL

## PART 2 - PRODUCTS

### PART 3 - EXECUTION

### 3.1 EXAMINATION

- A. Examine areas where registers and grilles are installed for compliance with requirements for installation tolerances and other conditions affecting performance of equipment.
- B. Proceed with installation only after unsatisfactory conditions have been corrected.

### 3.2 INSTALLATION OF REGISTERS AND GRILLES

- A. Install registers and grilles level and plumb.
- B. Outlets and Inlets Locations: Drawings indicate general arrangement of ducts, fittings, and accessories. Air outlet and inlet locations have been indicated to achieve design requirements for air volume, noise criteria, airflow pattern, throw, and pressure drop. Make final locations where indicated. For units installed in lay-in ceiling panels, locate units in the center of panel. Where architectural features or other items conflict with installation, notify Architect for a determination of final location.
- C. Install registers and grilles with airtight connections to ducts and to allow service and maintenance of dampers, air extractors, and fire dampers.

### 3.3 ADJUSTING

A. After installation, adjust registers and grilles to air patterns indicated, or as directed, before starting air balancing.

END OF SECTION 233713.23

## SECTION 235416.13 - GAS-FIRED FURNACES

## PART 1 - GENERAL

### 1.1 RELATED DOCUMENTS

A. The Drawings and General Provisions of the Contract, including the General and Supplementary Conditions, and the Division 01 Specification Sections, apply to this Section.

### 1.2 SUMMARY

- A. Section Includes:
  - 1. Gas-fired furnaces, condensing.

### B. Related Requirements:

- 1. Section 230548.13 "Vibration Controls for HVAC" for vibration isolation devices.
- 2. Section 231123 "Facility Natural-Gas Piping " for piping and connection requirements to natural-gas system.
- 3. Section 233300 "Air Duct Accessories" for flexible equipment connectors.
- 4. Section 238126 "Split-System Air-Conditioners" for connected DX cooling coil requirements.

### 1.3 ACTION SUBMITTALS

- A. Product Data: For each type of product.
  - 1. Include rated capacities, operating characteristics, furnished specialties, and accessories.
- B. Sustainable Design Submittals:
  - 1. Product Data: For ventilation equipment, indicating compliance with ASHRAE 62.1, Section 5 - "Systems and Equipment."
  - 2. Ventilation: Product Data for ventilation equipment, indicating compliance with ASHRAE 62.1, Section 5 "Systems and Equipment."
  - 3. Product Data: For adhesives, indicating VOC content.
  - 4. Laboratory Test Reports: For adhesives, indicating compliance with requirements for low-emitting materials.
- C. Shop Drawings:
  - 1. Include details of equipment assemblies. Indicate dimensions, weights, loads, required clearances, method of field assembly, components, and location and size of each field connection.
  - 2. Include diagrams for power, signal, and control wiring clearly differentiating between factory- and field-installed wiring.

### 1.4 INFORMATIONAL SUBMITTALS

A. Sample Warranty: For special warranty.

## 1.5 CLOSEOUT SUBMITTALS

- A. Operation and Maintenance Data: For each furnace to include in emergency, operation, and maintenance manuals.
  - 1. In addition to items specified in Section 017823 "Operation and Maintenance Data," include the following:
    - a. Furnace and accessories complete with controls.

## 1.6 MAINTENANCE MATERIAL SUBMITTALS

- A. Furnish extra materials described below that match products installed and that are packaged with protective covering for storage and identified with labels describing contents.
  - 1. Disposable Air Filters: Furnish one (1) complete set for each gas-fired furnace provided.

## 1.7 QUALITY ASSURANCE

- A. ASHRAE Compliance: Applicable requirements in ASHRAE 62.1, Section 5 "Systems and Equipment" and Section 7 "Construction and Startup."
- B. ASHRAE/IES 90.1 Compliance: Applicable requirements in ASHRAE/IES 90.1, Section 6 "Heating, Ventilating, and Air-Conditioning."
- C. Comply with NFPA 70.

### 1.8 WARRANTY

- A. Special Warranty: Manufacturer agrees to repair or replace the following components of furnaces that fail in materials or workmanship within specified warranty period:
  - 1. Warranty Period, Commencing on Date of Substantial Completion:
    - a. Furnace Heat Exchanger: Twenty (20) years.
    - b. Integrated Ignition and Blower Control Circuit Board: Ten (10) years.

## PART 2 - PRODUCTS

### 2.1 ASSEMBLY DESCRIPTION

A. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, Article 100, by a qualified testing agency, and marked for intended location and application.

### 2.2 GAS-FIRED FURNACES, CONDENSING

- A. Manufacturers: Daikin is the "Basis of Design". Subject to compliance with the requirements of this Sub-Section, available manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
  - 1. Amana Heating & Air Conditioning; under license to Goodman Company, L.P.
  - 2. Bryant; Carrier Global Corporation.
  - 3. Carrier Global Corporation.
  - 4. Goodman Manufacturing Company, L.P.
  - 5. Lennox Industries, Inc.; Lennox International.
  - 6. Ruud Air Conditioning Division.
  - 7. Trane.
  - 8. YORK; brand of Johnson Controls International plc, Building Solutions North America.
- B. Cabinet: Galvanized steel.
  - 1. Cabinet interior around heat exchanger shall be factory-installed insulation.
  - 2. Lift-out panels shall expose burners and all other items requiring access for maintenance.
  - 3. Factory paint external cabinets in manufacturer's standard color.
  - 4. Airstream Surfaces: Surfaces in contact with the airstream shall comply with requirements in ASHRAE 62.1.
- C. Fan: Centrifugal, factory balanced, resilient mounted, direct drive.
  - 1. Fan Motors: Comply with requirements in Section 230500 "Common Work Results for HVAC."
  - 2. Special Motor Features, ECM: Electronically controlled motor (ECM) controlled by integrated furnace/blower control.
- D. Type of Gas: Natural.
- E. Heat Exchanger:
  - 1. Primary: Aluminized steel.
  - 2. Secondary: Stainless steel.
- F. Burner:

- 1. Gas Valve: 100 percent safety modulating main gas valve, main shutoff valve, pressure regulator, safety pilot with electronic flame sensor, limit control, transformer, and combination ignition/fan timer control board.
- 2. Ignition: Electric pilot ignition, with hot-surface igniter or electric spark ignition.
- G. Gas-Burner Safety Controls:
  - 1. Electronic Flame Sensor: Prevents gas valve from opening until pilot flame is proven; stops gas flow on ignition failure.
  - 2. Flame Roll-out Switch: Installed on burner box; prevents burner operation.
  - 3. Limit Control: Fixed stop at maximum permissible setting; de-energizes burner on excessive bonnet temperature; automatic reset.
- H. Combustion-Air Inducer: Centrifugal fan with thermally protected motor and sleeve bearings prepurges heat exchanger and vents combustion products; pressure switch prevents furnace operation if combustion-air inlet or flue outlet is blocked.
- I. Furnace Controls: Solid-state board integrates ignition, heat, cooling, and fan speeds; adjustable fan-on and fan-off timing; terminals for connection to accessories; diagnostic light with viewport.
- J. Accessories:
  - 1. Combination Combustion-Air Intake and Vent: CPVC plastic fitting to combine combustion-air inlet and vent through roof.
  - 2. CPVC Plastic Vent Materials:
    - a. CPVC Plastic Fittings: Schedule 40, complying with ASTM F438, socket type.
    - b. CPVC Solvent Cement: ASTM F493.
- K. Capacities and Characteristics:
  - 1. See equipment schedule on Drawings for Capacities and Characteristics.

### 2.3 THERMOSTATS

- A. Controls shall comply with requirements in ASHRAE/IES 90.1, Section 6 "Heating, Ventilating, and Air Conditioning."
- B. Solid-State Thermostat: Wall-mounted, Wired or Wireless, programmable, microprocessor-based unit with automatic switching from heating to cooling, preferential rate control, seven-day programmability with minimum of four temperature pre-sets per day, vacation mode, and battery back-up protection against power failure for program settings.
- C. Control Wiring: Balanced twisted-pair cabling complying with requirements for Category 5e in Section 260523 "Control-Voltage Electrical Power Cables."
- 1. Manufacturers: Subject to compliance with requirements, available manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
  - a. Belden Inc.
  - b. Berk-Tek, a Leviton Company.
  - c. CommScope, Inc.
  - d. General Cable; Prysmian Group North America.
  - e. Hitachi Cable America Inc.
  - f. Mohawk; a division of Belden Networking, Inc.
  - g. West Penn Wire; brand of Belden, Inc.
- 2. Description: Shielded twisted pairs (FTP), No. 24 AWG, 100 ohms, four pair.
- 3. Cable Jacket Color: Blue.

### 2.4 AIR FILTERS

- A. Manufacturers: Subject to compliance with requirements, available manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
  - 1. Aprilaire; Research Products Corp.
  - 2. Filtrete Home Filtration Products; a 3M brand.
  - 3. General Filters, Inc.
  - 4. Permatron Corporation.
  - 5. American Air Filter International (AAF).
- B. Disposable Filters: 1-inch- thick fiberglass media with ASHRAE 52.2 MERV rating of 8 or higher, in sheet metal frame.

#### 2.5 REFRIGERATION COMPONENTS

- A. General Refrigeration Component Requirements:
  - 1. Refrigeration compressor, coils, and specialties shall be designed to operate with CFC-free refrigerants.
  - 2. Energy Efficiency: Equal to or greater than prescribed by ASHRAE/IES 90.1.
- B. Refrigerant Coil: Copper tubes mechanically expanded into aluminum fins. Comply with AHRI 210/240. Match size with furnace. Include condensate drain pan with accessible drain outlet complying with ASHRAE 62.1.
  - 1. Refrigerant Coil Enclosure: Steel, matching furnace and evaporator coil, with access panel and flanges for integral mounting at or on furnace cabinet and galvanized sheet metal drain pan coated with black asphaltic base paint.
- C. Refrigerant Line Kits: Annealed-copper suction and liquid lines factory cleaned, dried, pressurized with nitrogen, sealed, and with suction line insulated. Provide in standard lengths for installation without joints, except at equipment connections.

- 1. Flexible Elastomeric: Closed-cell, sponge- or expanded-rubber materials. Comply with ASTM C534/C534M, Type I, 1 inch thick.
- D. Air-Cooled Compressor-Condenser Unit:
  - 1. Casing: Steel, finished with baked enamel, with removable panels for access to controls, weep holes for water drainage, and mounting holes in base. Provide brass service valves, fittings, and gage ports on exterior of casing.
  - 2. Compressor: Hermetically sealed, Variable-speed scroll type.
    - a. Crankcase heater.
    - b. Restrained vibration isolation mounts for compressor.
    - c. Compressor motor shall have thermal- and current-sensitive overload devices, start capacitor, relay, and contactor.
    - d. Refrigerant Charge: [R-32 or [R-454B.
  - 3. Refrigerant Coil: Copper tube, with mechanically bonded aluminum fins, complying with AHRI 210/240, and with liquid subcooler.
  - 4. Heat-Pump Components: Reversing valve and low-temperature air cut-off thermostat.
  - 5. Fan: Aluminum-propeller type, directly connected to motor.
  - 6. Motor: Permanently lubricated, with integral thermal-overload protection.
  - 7. Low Ambient Kit: Permits operation down to 45 deg F.
  - 8. Mounting Base: Polyethylene.
- E. Capacities and Characteristics:
  - 1. Refer to equipment schedule(s) on Drawings for Capacities and Characteristics.

#### PART 3 - EXECUTION

#### 3.1 EXAMINATION

- A. Examine areas and conditions, with Installer present, for compliance with requirements for installation tolerances and other conditions affecting performance of the Work.
- B. Examine factory-installed insulation before furnace installation. Reject units that are wet, moisture damaged, or mold damaged.
- C. Examine roughing-in for gas and refrigerant piping systems to verify actual locations of piping connections before equipment installation.
- D. Proceed with installation only after unsatisfactory conditions have been corrected.

## 3.2 INSTALLATION

 A. Install gas-fired furnaces and associated fuel and vent features and systems according to NFPA 54.

- B. Base-Mounted Units: Secure units to substrate. Provide optional bottom closure base if required by installation conditions.
  - 1. Anchor furnace to substrate to resist code-required seismic acceleration.
- C. Controls: Install thermostats at mounting height of 60 inches above floor.
- D. Wiring Method: Install control wiring in accessible ceiling spaces and in gypsum board partitions where unenclosed wiring method may be used. Conceal control wiring except in unfinished spaces.
- E. Install roof-mounted compressor-condenser components per Drawing deatils and on equipment supports specified in Section 077200 "Roof Accessories." Anchor units to supports with removable, cadmium-plated fasteners.

### 3.3 PIPING CONNECTIONS

- A. Gas piping installation requirements are specified in Section 231123 "Facility Natural-Gas Piping." Drawings indicate general arrangement of piping, fittings, and specialties. Connect gas piping with union or flange and appliance connector valve.
- B. Install piping adjacent to equipment to allow service and maintenance.
- C. Vent and Outside-Air Connection, Condensing, Gas-Fired Furnaces: Connect plastic piping vent material to furnace connections and extend outdoors. Terminate vent outdoors with a cap and in an arrangement that will protect against entry of birds, insects, and dirt.
  - 1. Ream ends of pipes and tubes and remove burrs. Bevel plain ends of steel pipe.
  - 2. Remove scale, slag, dirt, and debris from inside and outside of pipe and fittings before assembly.
  - 3. Plastic Piping Solvent-Cement Joints: Clean and dry joining surfaces. Join pipe and fittings according to the following:
    - a. Comply with ASTM F402 for safe-handling practice of cleaners, primers, and solvent cements.
    - b. CPVC Piping: Join according to ASTM D2846/D2846M, Appendix.
  - 4. Slope pipe vent back to furnace or to outside terminal.
- D. Connect refrigerant tubing kits to refrigerant coil in furnace and to air-cooled compressor-condenser unit.
  - 1. Flared Joints: Use ASME B16.26 fitting and flared ends, following procedures in CDA's "Copper Tube Handbook."
  - 2. Soldered Joints: Apply ASTM B813, water-flushable flux, unless otherwise indicated, to tube end. Construct joints according to ASTM B828 or CDA's "Copper Tube Handbook," using lead-free solder alloy complying with ASTM B32.

## 3.4 DUCTWORK CONNECTIONS

A. Connect ducts to furnace with flexible connector. Comply with requirements in Section 233300 "Air Duct Accessories."

## 3.5 ELECTRICAL CONNECTIONS

- A. Connect wiring according to Section 260519 "Low-Voltage Electrical Power Conductors and Cables."
- B. Ground equipment according to Section 260526 "Grounding and Bonding for Electrical Systems."
- C. Install electrical devices furnished by manufacturer, but not factory mounted, according to NFPA 70 and NECA 1.
- D. Install nameplate for each electrical connection, indicating electrical equipment designation and circuit number feeding connection.
  - 1. Nameplate shall be laminated acrylic or melamine plastic signs, as specified in Section 260553 "Identification for Electrical Systems."
  - 2. Nameplate shall be laminated acrylic or melamine plastic signs with a black background and engraved white letters at least 1/2 inch high.

## 3.6 CONTROL CONNECTIONS

- A. Install control and electrical power wiring to field-mounted control devices.
- B. Connect control wiring according to Section 260523 "Control-Voltage Electrical Power Cables."

#### 3.7 STARTUP SERVICE

- A. Complete installation and startup checks according to manufacturer's written instructions and perform the following:
  - 1. Inspect for physical damage to unit casings.
  - 2. Verify that access doors move freely and are weathertight.
  - 3. Clean units and inspect for construction debris.
  - 4. Verify that all bolts and screws are tight.
  - 5. Adjust vibration isolation and flexible connections.
  - 6. Verify that controls are connected and operational.
- B. Adjust fan belts to proper alignment and tension.
- C. Start unit according to manufacturer's written instructions and complete manufacturer's operational checklist.

- D. Measure and record airflows.
- E. Verify proper operation of capacity control device.
- F. After startup and performance test, lubricate bearings and adjust belt tension.

#### 3.8 ADJUSTING

- A. Adjust initial temperature and humidity set points.
- B. Set controls, burner, and other adjustments for optimum heating performance and efficiency. Adjust heat-distribution features, including shutters, dampers, and relays, to provide optimum heating performance and system efficiency.

### 3.9 CLEANING

- A. After completing installation, clean furnaces internally according to manufacturer's written instructions.
- B. Install new filters in each furnace within 14 days after Substantial Completion.

### 3.10 FIELD QUALITY CONTROL

- A. Perform the following tests and inspections:
  - 1. Perform electrical test and visual and mechanical inspection.
  - 2. Leak Test: After installation, charge systems with refrigerant and test for leaks. Repair leaks, replace lost refrigerant, and retest until no leaks exist.
  - 3. Operational Test: After electrical circuitry has been energized, start units to confirm proper operation, product capability, and compliance with requirements.
  - 4. Verify that fan wheel is rotating in the correct direction and is not vibrating or binding.
  - 5. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
- B. Verify that vibration isolation and flexible connections properly dampen vibration transmission to structure.

#### 3.11 DEMONSTRATION

A. Train Owner's maintenance personnel to adjust, operate, and maintain condensing units. Refer to Section 017900 "Demonstration and Training."

END OF SECTION 235416.13

## SECTION 235533.16 - GAS-FIRED UNIT HEATERS

## PART 1 - GENERAL

## 1.1 SUMMARY

- A. Section Includes:
  - 1. Gas-fired unit heaters.

### PART 2 - PRODUCTS

### PART 3 - EXECUTION

#### 3.1 INSTALLATION

A. Install and connect gas-fired unit heaters and associated gas and vent features and systems according to [NFPA 54] [CSA B149.1], applicable local codes and regulations, and manufacturer's written instructions.

#### 3.2 EQUIPMENT MOUNTING

- A. Suspended Units: Suspend from substrate using threaded rods, spring hangers, and building attachments. Secure rods to unit hanger attachments. Adjust hangers so unit is level and plumb.
- B. Substrate-Mounted Units: Provide supports connected to substrate. Secure units to supports.
  - 1. Spring hangers[ and seismic restraints] are specified in [Section 230529 "Hangers and Supports for HVAC Piping and Equipment."] [Section 230548 "Vibration and Seismic Controls for HVAC."] [Section 230529 "Hangers and Supports for HVAC Piping and Equipment" and Section 230548 "Vibration and Seismic Controls for HVAC."]
  - 2. Threaded Rods, Spring Hangers, and Building Attachments: Comply with requirements in Section 230529 "Hangers and Supports for HVAC Piping and Equipment" and Section 230548 "Vibration and Seismic Controls for HVAC."
  - 3. Anchor the unit to resist code-required horizontal acceleration.

#### 3.3 CONNECTIONS

- A. Piping installation requirements are specified in other Sections. Drawings indicate general arrangement of piping, fittings, and specialties.
- B. Where installing piping adjacent to gas-fired unit heater, allow space for service and maintenance.

- C. Gas Piping: Comply with [Section 231123 "Facility Natural-Gas Piping."] [Section 231126 "Facility Liquefied-Petroleum Gas Piping."] Connect gas piping to gas train inlet; provide union with enough clearance for burner removal and service.
- D. Vent Connections: Comply with Section 235123 "Gas Vents."
- E. Ground equipment according to Section 260526 "Grounding and Bonding for Electrical Systems."
- F. Connect wiring according to Section 260519 "Low-Voltage Electrical Power Conductors and Cables."

## 3.4 ADJUSTING

- A. Adjust initial temperature and humidity set points.
- B. Adjust burner and other unit components for optimum heating performance and efficiency.
- 3.5 DEMONSTRATION
  - A. [Engage a factory-authorized service representative to train] [Train] Owner's maintenance personnel to adjust, operate, and maintain gas-fired unit heaters.

END OF SECTION 235533.16

# SECTION 237433 - DEDICATED OUTDOOR-AIR UNITS

## PART 1 - GENERAL

### 1.1 RELATED DOCUMENTS

A. The Drawings and General Provisions of the Contract, including the General and Supplementary Conditions, and the Division 01 Specification Sections, apply to this Section.

#### 1.2 SUMMARY

- A. Section Includes:
  - 1. Dedicated outdoor-air units.

### B. Related Requirements:

- 1. Section 077200 "Roof Accessories" for additional roof curb requirements.
- 2. Section 230548.13 "Vibration Controls for HVAC" for additional requirements.
- 3. Section 231123 "Facility Natural-Gas Piping" for connection requirements for the DOAS unit.
- 4. Section 233300 "Air Duct Accessories" for flexible equipment duct connectors.
- 5. Section 284621.11 "Addressable Fire-Alarm Systems" for smoke detector requirements.

## 1.3 DEFINITIONS:

- A. ECM: Electronically commutated motor.
- B. ISCOP: Integrated Seasonal Coefficient of Performance.
- C. ISMRE: Integrated Seasonal Moisture Removal Efficiency.
- D. MRC: Moisture Removal Capacity.

## 1.4 ACTION SUBMITTALS

- A. Product Data:
  - 1. For each type of product.
    - a. Include construction details, material descriptions, dimensions of individual components and profiles, and finishes.
    - b. Include rated capacities, operating characteristics, electrical characteristics, and furnished specialties and accessories.
    - c. Include unit dimensions and weight.
    - d. Include cabinet material, metal thickness, finishes, insulation, and accessories.

- e. Fans:
  - 1) Certified fan-performance curves with system operating conditions indicated.
  - 2) Certified fan-sound power ratings.
  - 3) Fan construction and accessories.
  - 4) Motor ratings, electrical characteristics, and motor accessories.
- f. Include certified coil-performance ratings with system operating conditions indicated.
- g. Include filters with performance characteristics.
- h. Include heat exchangers with performance characteristics.
- i. Include dampers, including housings, linkages, and operators.
- B. Sustainable Design Submittals:
  - 1. Product Data: Showing compliance with ASHRAE 62.1.
  - 2. Product Data: For air filtration performance.
  - 3. Product Data: For adhesives, mastics, and sealants, indicating VOC content.
  - 4. Laboratory Test Reports: For adhesives, mastics, and sealants, indicating compliance with requirements for low-emitting materials.
  - 5. Product Data: For refrigerants, indicating compliance with refrigerant management practices.
- C. Shop Drawings: For each dedicated outdoor-air unit.
  - 1. Include plans, elevations, sections, and mounting details.
  - 2. Include details of equipment assemblies. Indicate dimensions, weights, loads, required clearances, method of field assembly, components, and location and size of each field connection.
  - 3. Include diagrams for power, signal, and control wiring.

#### 1.5 INFORMATIONAL SUBMITTALS

- A. Sample Warranty: For manufacturer's warranty.
- B. Source quality-control reports.
- C. Startup service reports.
- D. Field quality-control reports.

#### 1.6 CLOSEOUT SUBMITTALS

A. Operation and Maintenance Data: For dedicated outdoor-air units to include in emergency, operation, and maintenance manuals.

## 1.7 MAINTENANCE MATERIAL SUBMITTALS

- A. Furnish extra materials that match products installed and that are packaged with protective covering for storage and identified with labels describing contents.
  - 1. Fan Belts: One (1) set for each belt-driven fan.
  - 2. Filters: One (1) set for each unit.
  - 3. Gaskets: One (1) set for each access door.

## 1.8 WARRANTY

- A. Warranty: Manufacturer agrees to replace components of dedicated outdoor-air units that fail in materials or workmanship within specified warranty period.
  - 1. Warranty Period for Compressors: Ten (10) years from date of Substantial Completion.
  - 2. Warranty Period for Heat Exchangers: Five (5) years from date of Substantial Completion.
  - 3. Warranty Period for Rotary Heat Exchangers: Five (5) years from date of Substantial Completion.

# PART 2 - PRODUCTS

# 2.1 PERFORMANCE REQUIREMENTS

- A. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, by an "NRTL" (nationally recognized testing laboratory), and marked for intended location and application.
- B. NFPA Compliance: Comply with NFPA 90A for design, fabrication, and installation of units and components.
- C. ASHRAE 62.1 Compliance: Applicable requirements in ASHRAE 62.1, Section 5 "Systems and Equipment" and Section 7 "Construction and Startup."
- D. ASHRAE 15 and ASHRAE 34 Compliance: For refrigeration system safety.
- E. ASHRAE/IES 90.1 Compliance: Applicable requirements in ASHRAE/IES 90.1, Section 6 "Heating, Ventilating, and Air-Conditioning."
- F. ASHRAE 84 Compliance: Comply with capacity ratings for heat-wheel or fixed plate energy-recovery equipment.

# 2.2 CAPACITIES AND CHARACTERISTICS

A. Refer to equipment schedule(s) on Drawings for Capacities and Characteristics.

## 2.3 DEDICATED OUTDOOR-AIR UNITS

- A. Manufacturers: Subject to compliance with the requirements of this Sub-Section, available manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
  - 1. AAON.
  - 2. Addison.
  - 3. Carrier.
  - 4. Daikin.
  - 5. Desert Aire.
  - 6. Greenheck.
  - 7. Munters Corporation.
  - 8. REZNOR, a brand of Nortek Global HVAC.
  - 9. TempMaster.
  - 10. Trane Co.
  - 11. York HVAC.
  - 12. XeteX.
- B. Source Limitations: Obtain dedicated outdoor-air units from single manufacturer.
- C. Unit Casing:
  - 1. General Fabrication Requirements for Casings: Formed and reinforced double-wall insulated panels, fabricated to allow removal for access to internal parts and components, with joints between sections sealed.
  - 2. Configuration: Horizontal unit with bottom discharge for roof-mounting installation.
  - 3. Double-Wall Configuration:
    - a. Outside Casing Wall: Galvanized steel, stainless steel in cooling coil section, minimum 18 gauge thick with manufacturer's standard finish, with pitched roof panels and knockouts with grommet seals for electrical and piping connections and lifting lugs.
    - b. Inside Casing Wall:
      - 1) Inside Casing, Burner Section: Galvanized steel, solid, minimum 14-gaugethick steel.
      - 2) Inside Casing, All Other Sections: Galvanized steel, solid.
    - c. Floor Plate: Reinforced metal surface; reinforced to limit deflection when walked on by service personnel. Insulation is provided below metal walking surface.
    - d. Roof: Standing seam or membrane; sloped to drain water.
    - e. Casing Insulation:
      - 1) Materials: Polyurethane foam insulation.
      - 2) Casing Panel R-Value: Minimum R-13.
      - 3) Insulation Thickness: 2 inches.
      - 4) Thermal Break: Provide continuity of insulation with no through-casing metal in casing walls, floors, or roofs of air-handling unit.

- 4. Airstream Surfaces: Surfaces in contact with airstream are to comply with requirements in ASHRAE 62.1.
- 5. Static-Pressure Classifications:
  - a. For Unit Sections Upstream of Fans: Minus 2 inches wg.
  - b. For Unit Sections Downstream and Including Fans: 3 inches wg.
- 6. Panels and Doors:
  - a. Panels:
    - 1) Fabrication: Formed and reinforced double-wall and insulated panels of same materials and thicknesses as casing.
    - 2) Fasteners: Two or more camlock-type fasteners for panel lift-out operation. Arrangement is to allow panels to be opened against airflow.
    - 3) Gasket: Neoprene, applied around entire perimeters of panel frames.
    - 4) Size: Large enough to allow unobstructed access for inspection and maintenance of unit's internal components.
  - b. Doors:
    - 1) Fabrication: Formed and reinforced double-wall and insulated panels of same materials and thicknesses as casing.
    - 2) Hinges: A minimum of two stainless steel piano hinge and two wedge-lever latches, operable from inside and outside. Arrange doors to be opened against airflow. Provide safety latch retainers on doors so that doors do not open uncontrollably.
    - 3) Gasket: Neoprene, applied around entire perimeters of panel frames.
    - 4) Size: Large enough to allow for unobstructed access for inspection and maintenance of air-handling unit's internal components.
  - c. Locations and Applications:
    - 1) Fan Section: Doors.
    - 2) Access Section: Doors.
    - 3) Gas-Fired Burner Section: Panels.
    - 4) Damper Section: Panels.
    - 5) Filter Section: Doors large enough to allow periodic removal and installation of filters.
    - 6) Relief Section: Doors.
- 7. Condensate Drain Pans:
  - a. Location: Each refrigerant coil and rotary heat exchanger.
  - b. Construction:
    - 1) Double-wall, non-corrosive polymer or stainless steel sheet.
  - c. Size: Large enough to collect condensate from cooling coils, including coil piping connections, coil headers, and return bends.

- d. Drain Connection:
  - 1) Located on one end of pan, at lowest point of pan.
  - 2) Terminated with threaded nipple.
  - 3) Minimum Connection Size: NPS 1-1/238.
- e. Slope: Minimum 0.125-inch/ft. slope, to comply with ASHRAE 62.1,] in at least two planes to collect condensate from cooling coils (including coil piping connections, coil headers, and return bends) and from humidifiers and to direct water toward drain connection.
- f. Length: Extend drain pan downstream from leaving face for distance to comply with ASHRAE 62.1.
- g. Width: Entire width of water-producing device.
- h. Depth: A minimum of 2 inches deep.
- D. Fans, Drives, And Motors:
  - 1. Fan and Drive Assemblies: Statically and dynamically balanced and designed for continuous operation at maximum-rated fan speed and motor horsepower.
  - 2. Supply-Air Fans and Relief-Air Fans: Centrifugal; galvanized or painted steel; mounted on solid-steel shaft.
    - a. Shafts: With field-adjustable alignment.
      - 1) Turned, ground, and polished hot-rolled steel with keyway.
    - b. Shaft Bearings:
      - 1) Heavy-duty, self-aligning, pillow-block type with an L-50 rated life of minimum 200,000 hours in accordance with ABMA 9.
    - c. Housings: Formed- and reinforced-steel panels to form curved scroll housings with shaped cutoff and spun-metal inlet bell.
      - 1) Bracing: Steel angle or channel supports for mounting and supporting fan scroll, wheel, motor, and accessories.
    - d. Housings, Plenum Fans: Steel frame and panel; fabricated without fan scroll and volute housing. Provide inlet screens for Type SWSI fans.
    - e. Backward-Inclined, Centrifugal Fan Wheels: Construction with curved inlet flange, backplate, backward-inclined blades welded to flange and backplate; steel hub riveted to backplate and fastened to shaft with setscrews.
    - f. Mounting: For internal vibration isolation. Factory mount fans with manufacturer's standard vibration isolation mounting devices having a minimum static deflection of 1 inch.
    - g. Shaft Lubrication Lines: Extended to a location outside the casing.
    - h. Flexible Connector: Factory fabricated with a fabric strip minimum 3-1/2 inches wide, attached to two strips of minimum 2-3/4-inch- wide by 0.028-inch- thick, galvanized-steel sheet.

- 1) Flexible Connector Fabric: Glass fabric, double coated with neoprene. Fabrics, coatings, and adhesives are to comply with UL 181, Class 1.
- 3. Drive, Direct: Factory-mounted direct drive.
- 4. Condenser-Coil Fan: Variable-speed propeller, mounted on shaft of permanently lubricated electronically commutated motors.
- 5. Motors:
  - a. Comply with NEMA designation, temperature rating, service factor, enclosure type, and efficiency requirements for motors specified in Section 230500 "Common Work Results for HVAC."
  - b. Motor Sizes: Minimum size as indicated. If not indicated, large enough so driven load will not require motor to operate in service factor range above 1.0.
  - c. Enclosure Type: Open, drip-proof (ODP) or Totally enclosed, fan cooled (TEFC).
  - d. Enclosure Materials: rolled, galvanized, and painted sheet steel or Cast iron.
  - e. Motor Bearings: <Insert requirements>.
  - f. Efficiency: Premium efficient as defined in NEMA MG 1.

## 2.4 MATERIALS

- A. Steel:
  - 1. ASTM A36/A36M for carbon structural steel.
  - 2. ASTM A568/A568M for steel sheet.
- B. Stainless Steel:
  - 1. Manufacturer's standard grade for casing.
  - 2. Manufacturer's standard type, ASTM A240/A240M for bare steel exposed to airstream or moisture.
- C. Galvanized Steel: ASTM A653/A653M.
- D. Aluminum: ASTM B209.
- E. Comply with Section 230546 "Coatings for HVAC" for corrosion-resistant coating.
- F. Corrosion-Resistant Coating: Coat [casing] [coils] [and] [fan guards] with a corrosion-resistant coating capable of withstanding a [3,000] <Insert time>-hour salt-spray test in accordance with ASTM B117.
  - 1. Standards:
    - a. ASTM B117 for salt spray.
    - b. ASTM D2794 for minimum impact resistance of 100 in-lb.
    - c. ASTM D3359 for cross-hatch adhesion of 5B.
  - 2. Application: [Immersion] [Spray].
  - 3. Thickness: [1 mil] <Insert measurement>.

4. Gloss: Minimum gloss of 50 gloss units on a single angle 60-degree meter.

# PART 3 - EXECUTION

## 3.1 EXAMINATION

- A. Examine areas, and conditions, with Installer present, for compliance with requirements for installation tolerances and other conditions affecting performance of the Work.
- B. Examine roughing-in for piping, ducts, and electrical systems to verify actual locations of connections before equipment installation.
- C. Examine roof curbs and equipment supports for suitable conditions where units will be installed.
- D. Proceed with installation only after unsatisfactory conditions have been corrected.

## 3.2 PIPING CONNECTIONS

- A. Piping installation requirements are specified in other Sections. Drawings indicate general arrangement of piping, fittings, and specialties.
- B. Where installing piping adjacent to units, allow space for service and maintenance.
- C. Connect piping to units mounted on vibration isolators with flexible connectors.
- D. Refrigerant Piping: Comply with applicable requirements in Section 232300 "Refrigerant Piping." Install shutoff valve and union or flange at each supply and return connection.
- E. Gas Piping: Comply with requirements in [Section 231123 "Facility Natural-Gas Piping."]
  [Section 231126 "Facility Liquefied-Petroleum Gas Piping."] Provide AGA-approved flexible connectors.
  - 1. Connect gas piping to furnace, full size of gas train inlet, and connect with union[, **pressure regulator**,] and shutoff valve with sufficient clearance for burner removal and service.
  - 2. Install AGA-approved flexible connectors.
- F. Hydronic Piping Connections:
  - 1. Comply with requirements in Section 232113 "Hydronic Piping" and Section 232116 "Hydronic Piping Specialties."
  - 2. Install shutoff valve and union or flange on each supply connection, and install balancing valve and union or flange on each return connection.
- G. Duct Connections:
  - 1. Comply with requirements in Section 233113 "Metal Ducts."
  - 2. Drawings indicate the general arrangement of ducts.

3. Connect ducts to units with flexible duct connectors. Comply with requirements for flexible duct connectors in Section 233300 "Air Duct Accessories."

# 3.3 ELECTRICAL CONNECTIONS

- A. Connect wiring in accordance with Section 260519 "Low-Voltage Electrical Power Conductors and Cables."
- B. Ground equipment in accordance with Section 260526 "Grounding and Bonding for Electrical Systems."
- C. Install electrical devices furnished by manufacturer, but not factory mounted, in accordance with NFPA 70 and NECA 1.
- D. Install nameplate for each electrical connection, indicating electrical equipment designation and circuit number feeding connection.
  - 1. Nameplate is to be laminated acrylic or melamine plastic signs, as specified in Section 260553 "Identification for Electrical Systems."
  - 2. Nameplate is to be laminated acrylic or melamine plastic signs with a black background and engraved white letters at least 1/2 inch high.

# 3.4 CONTROL CONNECTIONS

- A. Install control and electrical power wiring to field-mounted control devices.
- B. Connect control wiring in accordance with Section 260523 "Control-Voltage Electrical Power Cables."

# 3.5 STARTUP SERVICE

# A. [Engage a factory-authorized service representative to perform] [Perform] startup service.

- 1. Complete installation and startup checks in accordance with manufacturer's written instructions.
- 2. Inspect units for visible damage to furnace combustion chamber.
- 3. Perform the following operations for both minimum and maximum firing, and adjust burner for peak efficiency:
  - a. Measure gas pressure at manifold.
  - b. Measure combustion-air temperature at inlet to combustion chamber.
  - c. Measure flue-gas temperature at furnace discharge.
  - d. Perform flue-gas analysis. Measure and record flue-gas carbon dioxide and oxygen concentration.
  - e. Measure supply-air temperature and volume when burner is at maximum firing rate and when burner is off. Calculate useful heat to supply air.
- 4. Verify operation of remote panel, including pilot-light operation and failure modes. Inspect the following:

- a. High-limit heat exchanger.
- b. Alarms.
- 5. Inspect units for visible damage to refrigerant compressor, condenser and evaporator coils, and fans.
- 6. Start refrigeration system when outdoor-air temperature is within normal operating limits. and measure and record the following:
  - a. Cooling coil leaving-air, dry- and wet-bulb temperatures.
  - b. Cooling coil entering-air, dry- and wet-bulb temperatures.
  - c. Condenser coil entering-air dry-bulb temperature.
  - d. Condenser coil leaving-air dry-bulb temperature.
- 7. Simulate maximum cooling demand and inspect the following:
  - a. Compressor refrigerant suction and hot-gas pressures.
  - b. Short-circuiting of air through outside coil or from outside coil to outdoor-air intake.
- 8. Inspect casing insulation for integrity, moisture content, and adhesion.
- 9. Verify that clearances have been provided for servicing.
- 10. Verify that controls are connected and operable.
- 11. Verify that filters are installed.
- 12. Clean coils and inspect for construction debris.
- 13. Clean furnace flue and inspect for construction debris.
- 14. Inspect operation of power vents.
- 15. Purge gas line.
- 16. Inspect and adjust vibration isolators and seismic restraints.
- 17. Verify bearing lubrication.
- 18. Clean fans and inspect fan-wheel rotation for movement in correct direction without vibration and binding.
- 19. Adjust fan belts to proper alignment and tension.
- 20. Start unit.
- 21. Inspect and record performance of interlocks and protective devices, including response to smoke detectors by fan controls and fire alarm.
- 22. Operate unit for run-in period.
- 23. Calibrate controls.
- 24. Adjust and inspect high-temperature limits.
- 25. Inspect outdoor-air dampers for proper stroke[ and interlock with return-air dampers].
- 26. Verify operational sequence of controls.
- 27. Measure and record the following airflows. Plot fan volumes on fan curve.
  - a. Supply-air volume.
  - b. Relief-air flow.
  - c. Outdoor-air flow.
- B. After startup, change filters, verify bearing lubrication, and adjust belt tension.
- C. Remove and replace components that do not properly operate, and repeat startup procedures as specified above.

D. Prepare written report of the results of startup services.

## 3.6 ADJUSTING

- A. Adjust initial temperature and humidity set points.
- B. Set field-adjustable switches and circuit-breaker trip ranges as indicated.
- C. Occupancy Adjustments: When requested within [12] <Insert number> months from date of Substantial Completion, provide on-site assistance in adjusting system to suit actual occupied conditions. Provide up to [two] <Insert number> visits to Project during other-than-normal occupancy hours for this purpose.

## 3.7 CLEANING

A. After completing system installation; testing, adjusting, and balancing dedicated outdoor-air unit and air-distribution systems; and completing startup service, clean air-handling units internally to remove foreign material and construction dirt and dust. Clean fan wheels, casings, dampers, coils, and filter housings, and install new, clean filters.

## 3.8 DEMONSTRATION

A. [Engage a factory-authorized service representative to train] [Train] Owner's maintenance personnel to adjust, operate, and maintain units.

END OF SECTION 237433